



DEPARTMENT OF THE NAVY
HEADQUARTERS UNITED STATES MARINE CORPS
3000 MARINE CORPS PENTAGON
WASHINGTON, DC 20350-3000

MCO 13670.1B
ASL
3 Jan 12

MARINE CORPS ORDER 13670.1B

From: Commandant of the Marine Corps
To: Distribution List

Subj: MANAGEMENT AND ADMINISTRATION OF UNITED STATES MARINE
CORPS MOBILE FACILITY (MF) PROGRAM AND RELATED EQUIPMENT

Ref: (a) DOD 4500.9-R, "Defense Transportation Regulations,"
Part VI, August 2011
(b) MIL-HDBK-138B, January 1, 2002
(c) COMNAVAIRFORINST 4790.2A
(d) MCWP 3-21.2
(e) NAVAIRINST 13670.1C
(f) NAVAIR 17-1-125
(g) NAVAIR 19-25-177
(h) AG-360MF-IIN-000
(i) AG-360MF-CCD-000
(j) SECNAV M-5210.1

Encl: (1) Sample Mobile Facility Deployable Readiness Report
(2) Sample MF Transfer/Receipt Message
(3) Sample MF Disposition Request Message
(4) Sample MF Receipt/Transfer/Survey Procedure Checklist
(5) Sample Generator/Ancillary Equipment Rework Request
(6) USMC MF TBA by Configuration Code
(7) USMC MF TBA by Contingency Support Package
(8) USMC MF TBA by Division
(9) USMC MF TBA Support Equipment by Configuration Code
(10) Cross Reference
(11) Sample MF User O-Level Maintenance Syllabus

1. Situation. To promulgate policies, procedures, and guidance regarding the management and administration of Mobile Facilities (MFs) and related equipment assigned to U.S. Marine Corps commands.

2. Mission. To provide Marine Corps Forces with deployable and environmentally controlled shelters for aircraft logistic support in tactical and garrison environments. All MFs and ancillary equipment will be managed, utilized and maintained in accordance

DISTRIBUTION STATEMENT A: Approved for public release;
distribution is unlimited.

with references (a) through (j) and policies set forth in this Order. Successful execution of this program relies heavily on proper management at all levels, but mission accomplishment requires appropriate actions at the user levels.

3. Execution

a. Commander's Intent and Concept of Operations

(1) Commander's Intent. Ensure the readiness of all Mobile Facilities and ancillary equipment by providing support and sustainment in accordance with established policies and procedures.

(2) Concept of Operations. This program must be conducted on multiple levels.

(a) Headquarters Marine Corps (HQMC). The Aviation Support Logistics Avionics section (ASL-34) provides oversight and guidance to subordinate elements. ASL-34 also acts as the liaison and establishes the mobile facility program requirements, on behalf of the Deputy Commandant of Aviation, to the NAVAIR MF Program Manager.

(b) Marine Forces (MARFORCOM/MARFORPAC/MARFORRES). The MARFOR Aviation Logistics Division (ALD) Avionics section provides oversight and guidance to subordinate elements. The MARFOR also acts as the liaison to HQMC (ASL-34) and the NAVAIR MF Program Manager.

(c) Marine Aircraft Wing (MAW). The Marine Aircraft Wing (MAW) ALD Avionics branch manages all MFs and ancillary equipment and coordinates the distribution of MF assets between higher and lower echelons.

(d) Marine Aviation Logistics Squadron (MALS). The Marine Aviation Logistics Squadron (MALS) Avionics Officer (AVO) is responsible for the day to day operation, maintenance and management of all MF assets within the Marine Aircraft Group, to include supported units, such as Marine Wing Support Squadron (MWSS) and the Marine Air Control Squadron (MACS).

(e) Supported Units/Training Commands. The Commanding Officer/Officer-in-Charge (CO/OIC) of supported units using MF assets, must work in concert with the MALS AVO to ensure the successful execution of the MF program.

b. Subordinate Element Missions

(1) HQMC ASL shall:

(a) Be responsible for the management and the coordination of the U.S. Marine Corps MF program.

(b) Serve as the Table of Basic Allowance (TBA) program sponsor who publishes the mobile facilities and associated ancillary equipment requirements in support of Marine Corps aviation.

(c) Collaborate with the MARFORs and the NAVAIR MF Program Office for production priorities, MF TBA requirements and incorporation. Annual review of the TBA will address any updates.

(2) The MARFOR shall:

(a) Be responsible for the management and the coordination of the MARFOR MF program in accordance with references (a) through (j) and policies set forth in this Order.

(b) Assign, in writing, the MARFOR Mobile Facility Coordinator (MFC).

(c) Require the MARFOR MFC to be a certified International Convention for Safe Containers (CSC) inspector.

(d) Publish an MF inspection schedule via Naval message to ensure the MAW MF program is inspected by the MARFOR MFC biennially using the current CSEC checklist.

(e) Forward biennial inspection results in Naval message format to CMC (ASL-34).

(f) Maintain file copies of the MF biennial inspection for a minimum of four years per reference (j).

(g) Upon MF survey approval, ensure MF is disposed of in accordance with this Order.

(h) Coordinate with the other MARFORs to establish MF requirements and production priorities. Deliver consolidated TBA inputs and production prioritization in email format to ASL-34B annually NLT then the 1st of March.

3 Jan 12

(3) The MAW shall:

(a) Be responsible for the management and coordination of the MF program in accordance with references (a) through (j) and policies set forth in this Order.

(b) Assign, in writing, a MAW MFC.

(c) Ensure that the MAW MFC is a certified CSC inspector.

(d) Ensure the best possible MF deployable posture is maintained using assets within the MAW, through close coordination with MARFOR ALD-E and strict adherence to the CSC program.

(e) Ensure timely and accurate submission of MF reports as required.

(f) Ensure that the MAW MFC accompanies the MARFOR MFC during the biennial MARFOR inspection of the MAW.

(g) Ensure that the MAW program is inspected by the MAW MFC annually using the current CSEC checklist. The annual Wing Inspection will be performed within six months after the MARFOR MF inspection.

1. Forward inspection results to CMC (ASL-34) in Naval message format via the MARFOR.

(h) Inform MARFOR ALD-E of changes in status of MF program equipment as they occur.

(i) Maintain file copies of the MF annual inspection for a minimum of four years per reference (j).

(j) Upon MF survey approval, ensure MF is disposed of per this Order.

(k) Provide a quarterly MF Deployable Readiness Report (MFDRR) IAW enclosure (1) to HQMC DC(A) ASL via the MARFOR

(4) The MALS shall:

(a) Manage the local MF program, to include all divisions within MALS, deployed and deploying units and other supported units with MF requirements, in accordance with references (a) through (j) and policies set forth in this Order.

(b) Assign, in writing, a MALS MFC.

(c) Ensure the MALS MFC holds the 6499 MOS and is a certified CSC inspector.

(d) Ensure the MALS MFC conducts periodic (semi-annual) site visits to supported units to assist in management of the MF program.

(e) Ensure the best possible MF deployable posture through close coordination with the MAW MFC and strict adherence to the CSC program. Ensure CSC inspections are kept current.

(f) Ensure that at least four members of the unit are certified CSC inspectors and all CSC inspectors are also CDIs.

(g) Ensure the established training tracks are being utilized to qualify user (i.e., department, division and section) personnel in MF O-Level maintenance IAW enclosure (11). Selected user personnel shall be trained to the level necessary to perform collateral duty inspections (i.e., scheduled maintenance and corrosion control). This training will be documented in the Collateral Duty Inspector (CDI) and miscellaneous sections, respectively, of the individual's training jacket. Training will be conducted by W/C 60C.

(h) Ensure that Logbook and Inventory Records (LIRs) and OPNAV 4790/51, Support Equipment Custody and Maintenance History Records are maintained by the Aircraft Maintenance Administration Specialist (6046) Marine in work center 60C in accordance with references (c) and (j).

(i) Ensure that Quality Assurance conducts program audits on work center 60C as required by reference (c).

(j) Ensure receipt and transfer messages that are required by this Order are prepared and submitted per enclosure (2). Receipt and transfer messages shall be maintained for a minimum of one year per reference (j).

(k) Maintain file copies of the MF annual inventory for a minimum of four years per reference (j).

(l) Submit MF disposition/survey requests per enclosure (3), as required. Upon survey approval, prepare MF for disposal per this Order. MF disposition/survey approvals shall be maintained for a minimum of two years per reference (j).

(5) Supported Units Commanding Officer/Officer-in-Charge shall:

(a) Assign, in writing, an MFC.

1. The MFC will be directly responsible to the CO/OIC for implementation, coordination, and management of the unit's MF program in accordance with references (a) through (j) and policies set forth in this Order.

2. The MFC will be the liaison between their unit and the MFC of the MALS providing I-Level support.

(b) Ensure that the MFC accompanies the supporting MALS MFC during site visits.

(c) Ensure the best possible MF deployable posture through close coordination with the MALS MFC and strict adherence to the CSC program.

(d) Ensure that the CSC inspections are kept current on all active MFs. The MAW or supporting MALS CSC inspector may be used for CSC program required re-inspections.

(e) Enforce a comprehensive MF maintenance program, per applicable references and this Order, to provide maximum support with an emphasis on readiness. This will be accomplished by performing all user-related maintenance actions and by coordinating with the supporting MALS production control for those repair actions requiring support from W/C 60C.

(f) Ensure that a minimum of two personnel per section are trained to a level necessary to perform limited MF QA inspections (e.g., scheduled maintenance and corrosion control). The supporting MALS W/C 60C will provide the training necessary to qualify user personnel in MF O-Level maintenance.

(g) Maintain a current MFTOOL inventory database of all MF equipment supported by the MALS.

(h) Report all MF movement, inventory and updates to the supporting MALS.

c. Coordinating Instructions

(1) Mobile Facilities Coordinator (MFC). The MFC shall be a Staff Noncommissioned Officer (SNCO) that holds the 6499

MOS. The MFC shall maintain a copy of this Order and be familiar and comply with references (a) through (j) and policies set forth in this Order. The MFC shall ensure that the subject line of all Naval messages regarding MF program equipment begins with "SE-4 MOBILE FACILITY (MF)."

(2) International Convention for Safe Containers (CSC). Mobile facilities are military dry cargo intermodal containers constructed to International Organization for Standardization (ISO) standards and support multiple modes of handling and transportation. Mobile Facilities are required to meet ISO container and international shipping standards. All active MFs must comply with international regulations governing intermodal dry cargo containers. Mobile Facilities, therefore, require certification under the CSC Program.

(a) Every active MF is required to have a CSC inspection data plate permanently attached. The data plate will display the next CSC inspection due date.

(b) Inspections are conducted in accordance with reference (b).

(c) Mobile Facilities that fail a CSC inspection or whose CSC inspection due date has lapsed will be considered a CSC failure and are, therefore, non-deployable until such time that the material condition of the MF has been restored to a passing condition.

(d) Inspectors must be initially certified by successful completion of the AMMO-43 Intermodal Dry Cargo Container/CSC resident Course. Recertification may be accomplished by either the resident or non-resident course.

1. Nominees should be screened, qualified and certified with the same degree of consideration given a CDI.

2. Enrollment is requested in accordance with established training procedures.

3. Each CSC Inspector shall submit a copy of their certificate to the MAW MFC who will maintain a copy and forward to the MARFOR MFC.

(3) Movement Control. The term movement applies to deployments, transfers and temporary loans. Movement control is a high impact issue because it has a direct effect on inventory

3 Jan 12

control. All movement must be approved prior to execution and must be reported to the MF Program Office via Naval message, citing the approval authority, to facilitate inventory control. As with all matters pertaining to MFs and ancillary equipment, movement must be coordinated through the MALS MFC.

(a) Intra-wing movement must be approved by MAW ALD Avionics. Intra-wing movement is defined as any movement where the MF/equipment will remain in the custody of a MALS, or supported unit, assigned to MAW.

(b) Any movement of MFs and/or ancillary equipment Outside Continental United States (OCONUS) (with the exceptions of intra-wing movement within 1st MAW, and the MEU Aviation Combat Element (ACE) onboard ship) must be approved by the MARFOR.

(c) Inter-wing movement, when the MF/equipment will be in the physical custody of a unit not within the MAW, must be approved by the MARFOR.

(d) Movement of MF's housing hard-mounted Individual Material Readiness List (IMRL) equipment outside of the parent MALS must be approved by the IMRL TYPE COMMANDER (TYCOM) (COMNAVAIRFOR/COMNAVAIRFORRES) as well as the appropriate MF authority.

(e) Prior to movement, the MFs must be prepared in accordance with reference (h) and inspected in accordance with reference (b). MF must have a minimum of 60 days remaining on the CSC inspection due date at the time of movement.

(f) No MF will be transferred with equipment shortages unless approved by the MF Program Office. All shortages will be annotated on the transfer Naval message and in the LIR.

(g) Authorized modes of transportation are: air-ride truck, ship, or air (when operational considerations require urgent delivery). Rail transportation is not authorized. NOTE: Air louvers must be opened during air transport to prevent over-pressurization of MFs.

(h) All documentation of movement controls will be maintained per reference (j) as appropriate.

(4) Inventory Control. A current inventory of all assigned MF program equipment will be maintained by the MFC using the MF Tool database. This format will be used to submit the

3 Jan 12

annual inventory report. Each MALS inventory will include all MF program equipment used by supported units (MWSS, MCC, etc).

(a) Report any changes to the MF inventory database, as they occur, to the next higher echelon.

(b) As MFs are received, they will be assigned to a specific Contingency Support Package, Division, and Work Center/Branch based on the Configuration Code, needs of the unit, and consideration for older MFs that have reached their service life. To assist in this task, utilize the MF Table of Basic Allowances (TBA), enclosure (6). A procedure checklist, enclosure (4), will be initiated for every MF transferred/received and a completed copy retained in the LIR for a minimum of two years per reference (j).

(c) All receipts and transfers of MFs or ancillary equipment will be reported via Naval message within 48 hours using enclosure (2) format.

(d) Receipt, transfer and disposition/survey messages, and inventories, for all MF TBA equipment will be submitted by the supporting MALS to the MF Program Office via the respective chain of command.

(e) Mobile Facility transactions, such as receipts, transfers, rework, and surveys, will be annotated in the "REMARKS" column of the inventory report by entering the date-time-group (DTG) and the originating activity of the message directing the action.

(f) Mobile Facilities that are assigned to a MALS per the MF TBA will not be assigned to, or used by, organizational or other activities unless specifically directed by MARFOR ALD-E.

(g) Maximum effort shall be made to utilize the TQG storage facility in MCB Albany in an effort to reduce fleet maintenance and increase TQG readiness. A minimum amount of TQGs should be retained for training purposes at each MALS. Each MARFOR should determine the appropriate quantity of TQGs required at each MALS to accommodate this training.

(h) MARFOR and Wing MFCs will verify the accuracy of each unit's MFDRR, utilizing MFTOOL, during their annual/biennial inspections.

(5) Maintenance. Maintenance concepts and maintenance management systems for MF program equipment are the same as

3 Jan 12

delineated in reference (c) for Support Equipment. Mobile Facilities and related equipment, in use or in storage, will be maintained in a state of operational readiness, in accordance with references (c), (f) and (g).

(a) O-Level maintenance will be performed by the MF user (i.e., sections and work centers that physically occupy MFs). O-Level maintenance involves conducting the Preventive Maintenance (PM) Inspections on the Environmental Control Unit (ECU) and MF, keeping the ECU filters clean and unobstructed, keeping the inside and outside of MFs clean, changing light bulbs, keeping hinges lubricated and corrosion free, touch up painting, corrosion control and surface corrosion repair. No power tools are authorized in the performance of O-Level corrosion control. Severe levels of corrosion requiring the use of power tools to complete will be considered I-Level maintenance. The NCOIC of 60C will determine the level of repair on any issue in question.

(b) The term I-Level within the MF program refers to that level of maintenance performed by the MALS W/C 60C. I-Level involves all maintenance, beyond that of the O-level, necessary to return an MF or ECU to ready-for-use (RFU) condition, to include the incorporation of applicable Technical Directives (TDs). I-Level maintenance is provided by the supporting MALS for the training commands, MWSS and the MACS.

(c) Work Center 60C is responsible for all maintenance requirements, to include TDs, corrosion control and surface corrosion repair on the MF program ancillary equipment, e.g., Complexing/Decomplexing Tools (CDTs), generators, frequency converters, and scaffolding.

(d) ECU access panels and doors, if removed, will be preserved and stored in an area protected from the elements. MF personnel door assemblies, if removed, will be properly stored to prevent damage and in an area protected from the elements. Side opening MF panels will be properly stored in the fixtures provided. CDTs and generators (not required for periodic use) shall be preserved and properly stored when not in use.

(e) In garrison, MF generators, and associated equipment, that are not in a state of preservation will be operated one hour per week, or as local regulations permit, to prevent generator down time and provide operator training.

3 Jan 12

(f) MF generator/ancillary equipment rework shall be requested, via Naval message, in the format provided in enclosure (5).

(g) The unauthorized alteration or modification of an MF from its original configuration, or intended use, is strictly prohibited. The temporary addition or relocation of original internal MF equipment requires approval from the unit MFC and all changes will be documented in the LIRS. Requests for modifications that permanently alter the MF's configuration will be submitted to the MF Program Office via MARFOR ALD and MAW ALD-E.

(6) MF Complexes. There are many factors to consider when complexing MFs, such as, power requirements, fire and safety regulations and overall size limitations. Additionally, ensure all local, state, and federal Environmental Protection Agency (EPA) regulations are followed to include painting restrictions, oil/water separators, hazardous material containment and emissions, etc. All regulations, requirements and restrictions for MF complexes are provided in reference (h).

(7) Equipment Disposition Requests. If a CSC inspector determines that an MF is damaged beyond economical repair, that MF is a candidate for survey.

(a) Disposition requests for mobile facilities and ancillary equipment will be submitted to MAW MFC via Naval message, in the format provided in enclosure (3). The MAW MFC must validate the request. If the MAW concurs with the request, it must be forwarded to MARFOR ALD for concurrence/endorsement. The request will then be forwarded to the MF Program Office for final disposition approval.

(b) If MF survey disposition is approved, surveyed MFs must be sent to the Defense Reutilization and Marketing Office (DRMO) in accordance with local instructions. A completed copy of DD Form 1348-1A (Disposal Turn-In Document) must be forwarded to NAVAIR's MF Program Office. Any request for retention of surveyed MFs must be submitted via Naval message to HQMC (ASL-34) and endorsed by the respective MAW and MARFOR, for approval. Upon approval, contact the nearest DRMO to complete the DD Form 1348-1A to avoid any unnecessary transportation disposal costs.

(c) No surveyed MF will be physically complexed with, or electrically connected to, an active MF or MF complex.

3 Jan 12

(d) Surveyed MFs, which are electrically connected to a separate power source other than active MFs, must remain in their original electrical configuration to include proper grounding per reference (h).

(e) Once an MF has been approved for survey, the following will be complied with by the surveying activity:

1. Permanently remove or paint over all MF markings or decals as applicable and remove the CSC data plate.

2. Clearly stencil "SURVEYED-NOT FOR EMBARK" in six-inch red letters, centered on both side walls and centered above the doors on both ends. Stencil the DTG of the MF Program NAVAIR authorization message in six-inch red letters centered below the SURVEYED markings on both side walls of the MF.

3. All butting kits, walkways, environmental control units, and fire bottles will be removed from a surveyed MF prior to its disposition. Should a surveyed MF be connected to a power source, a fire bottle must be maintained within the MF.

4. Complete Receipt/Transfer/Survey procedures as per enclosure (4).

5. Comply with survey disposition instructions for the MF LIR as outlined in the MF Program Office disposition message.

(f) Surveyed MFs will not have equipment installed for which a "SHORTAGE" is noted in any active (non-surveyed) MF.

(g) Surveyed MFs are not deployable and cannot be stacked or hoisted via ISO corners.

(h) An Environmental Control Unit is not an integral part of an MF; therefore, the ECU will not be disposed of with the MF. No RFU ECU will be placed in a surveyed MF if an active MF requires one. Work Center 60C will maintain a signed custody card on each ECU being used in a surveyed MF. All scheduled and unscheduled maintenance will continue on every active ECU. Non-RFU Environmental Control Units will be disposed of per their source, maintenance, and recoverability (S, M, and R) codes.

3 Jan 12

4. Administration and Logistics

a. Personnel

(1) MALS W/C 60C is established to provide I-Level support for MFs and MF ECUs. W/C 60C is also responsible for all scheduled and unscheduled maintenance of the MF ancillary equipment. The Table of Organization for each MALS provides a basic "core" of personnel that hold the 6499 MOS. Various Organizational level T/Os hold additional 6499 Augmentees in support of W/C 60C.

(2) Each department, division or section using MFs will continue to perform O level maintenance to their associated MFs.

b. Funding Responsibilities and Cognizance

(1) The NAVAIRHQ MF Program Branch Head has total budgeting, funding, and acquisition responsibility for all MFs and related equipment acquired in support of the NAVAIR mission. The NAVAIRHQ MF Program Branch Head has configuration and outfitting responsibility for all MFs acquired in support of specific NAVAIR weapon system projects and funded through the appropriate program management or program coordinator office.

(2) The NAVAIR MF Program Management Office has responsibility for all MFs acquired under the MFs subline in the Common Support Equipment APN-7 (BA-7) P-I Budget Line Item. The NAVAIR MF Program Management Office has direct budgeting/funding responsibility in the Operation and Maintenance, Navy (O&M,N) appropriation for configuration/equipment installation requirements for those MFs procured in support of the NAVAIR mission whether for a specific weapon system or a common requirement. Reference (c) authorizes the use of Aviation Fleet Maintenance funds for organizational and intermediate level maintenance of MF equipment used in support of aircraft maintenance. Operating costs, such as those needed for engine oil, filters, and fuel for MF equipment must be budgeted and funded per TYCOM and local instructions.

c. Records Management. Records created as a result of this Order shall be managed according to National Archives and Records Administration approved dispositions per reference (j) to ensure proper maintenance, use, accessibility and preservation, regardless of format or medium.

5. Command and Signal

a. Command. This Order is applicable to the Marine Corps Total Force.

b. Signal. This Order is effective date signed.


T. G. ROBLING
Deputy Commandant for Aviation

DISTRIBUTION: PCN 10214780000

Copy to: CMC (ASL-34)
COMMARFORCOM
COMMARFORPAC
COMMARFORRES
1STMAW ALD
2DMAW ALD
3DMAW ALD
4THMAW ALD
MALS-11
MALS-12
MALS-13
MALS-14
MALS-16
MALS-24
MALS-26
MALS-29
MALS-31
MALS-36
MALS-39
MALS-40
MALS-41
MALS-49

Sample Mobile Facility Deployable Readiness Report

FM XMAW(UC)//(Originating MAW)
TO CMC WASHINGTON DC AVN ASL(UC)//
CC COMMARFORXXX ALD(UC) //
COMNAVAIRSYS COM PATUXENT RIVER MD(UC)//
MAG XX(UC)// (Each MAG within the Wing)
MALS XX(UC)// (Each MALS within the Wing)
UNCLAS //N13670//
MSGID/GENADMIN/XMAW//
SUBJ/SE-4 MOBILE FACILITY DEPLOYABLE READINESS REPORT (MFDRR)//
REF/A/DOC/MCO 13670.1X/DD MMM YY//
AMPN/REF A IS THE Marine Corps ORDER FOR MANAGEMENT AND
ADMINISTRATION OF MARINE AVIATION MF'S//
POC/(APPLICABLE INFO FOR NAME OF WING POC)//

RMKS/ 1. IAW REF A THE FOLLOWING MFDRR IS SUBMITTED FOR
XMAW(Applicable Wing) READ IN SIX (6) COLUMNS:

MOBILE FACILITIES

UNIT	%FSSD	%PSSM	%PSSI	%DSSN	NOTES
MALS-11	78%	15	5%	2%	1

TQGs

UNIT	%FSSD	%PSSM	%PSSI	%DSSN	NOTES
MALS-11	78%	15	5%	2%	2

STATIC CONVERTERS/MMG-1As

UNIT	%FSSD	%PSSM	%PSSI	%DSSN	NOTES
MALS-11	78%	15	5%	2%	

OTHER ANCILLARY SUPPORT EQUIPMENT

UNIT	%FSSD	%PSSM	%PSSI	%DSSN	NOTES
MALS-11	78%	15	5%	2%	3

2. THE MFDRR CODES ABOVE ARE DEFINED AS:

(FSSD) FULL SYSTEM SUPPORT, DEPLOYABLE.

THE MF AS WELL AS THE IMRL/ANCILLARY SUPPORT EQUIPMENT ARE RFI AND DEPLOYABLE, ACCORDING TO MCO 13670.1 AND NAVAIRINST 13670.1

(PSSM) PARTIAL SYSTEM SUPPORT, MOBILE FACILITY.

IMRL IS RFI BUT THE MF IS NRFI AND NOT DEPLOYABLE, ACCORDING TO MCO 13670.1 AND NAVAIRINST 13670.1

(PSSI) PARTIAL SYSTEM SUPPORT, IMRL.

THE MF IS RFI AND DEPLOYABLE BUT THE IMRL IS NRFI OR NOT DEPLOYABLE, ACCORDING TO MCO 13670.1 AND NAVAIRINST 13670.1

(DSSN) DEGRADED SYSTEM SUPPORT, NON-DEPLOYABLE.

THE MF AS WELL AS THE IMRL/ANCILLARY SUPPORT EQUIPMENT ARE NRFI AND NON-DEPLOYABLE, ACCORDING TO MCO 13670.1 AND NAVAIRINST 13670.1.

3. NOTES:

1. (15) MFS DOWN FOR CSC INSPECTIONS.
2. (4) TQGS REQUIRE FUEL PUMPS, EI SUBMITTED.
3. (2) CDT UNITS ON ORDER.//

Sample MF Transfer/Receipt Message

FM MALS XX(UC)// (Originating MALS)
TO (RECEIVING ACTIVITY)//
CC CMC WASHINGTON DC AVN ASL(UC)//
COMNAVAIRSYSCOM PATUXENT RIVER MD(UC)//
COMMARFORXXX ALD(UC)//
MAG XX(UC)// (Parent MAG of the originating MALS)
MAG XX(UC)// (Parent MAG of MALS that transferred or received the MF)
MALS XX(UC)// (That transferred or received the MF)
UNCLAS //N13670//
MSGID/GENADMIN/MALS XX//
SUBJ/SE-4 MOBILE FACILITY (MF) TRANSFER/RECEIPT//
REF/A/DOC/NAVAIRINST 13670.1C/26JUN08//
REF/B/DOC/MCO 13670.1/DATE//
REF/C/DOC/COMMARFORXXX/DATE//
REF/D/RMG/ (if Receipt, Agency/Unit that shipped MF) (if Transfer, Transfer Authority message or as applicable, reference conversation or other communication that authorized the movement)
NARR/REF'S A THRU C ARE MF INST/ORDERS FOR MANAGEMENT AND ADMINISTRATION OF MARINE AVIATION MF'S. REF D IS (as applicable) NAVAIR MFCS NORFOLK VA MSG ANNOUNCING SHIPMENT OF MF or CG XX MAW REQ TO TRANSFER MF, etc.//
POC/(APPLICABLE INFO FOR NAME OF MFC OR DESIGNATED PERSONNEL)//
RMKS/ 1. IAW REF'S A THRU C , AND IRT REF D THE FOLLOWING MF'S/EQUIPMENT HAVE BEEN TRANSFERRED/RECEIVED FROM BY THIS COMMAND:
CONFIG SERNO ISO NO CSC DUE ECU SERNO
2. (Comments on quality of MF are required in this paragraph, i.e.: UNIT RECEIVED/TRANSFERED SEALED AND COMPLETE, UNIT RECEIVED/TRANSFERED WITH DAMAGED ISO CORNER, SHEARED RIVETS, ETC.)//

Enclosure (2)

Sample MF Disposition Request Message

FM MALS XX(UC) (Originating MALS)
TO CG XXX MAW ALD(UC)//
CC // CMC WASHINGTON DC AVN ASL(UC)//
COMNAVAIRSYSCOM PATUXENT RIVER MD(UC)//
COMMARFORXXX ALD(UC)//
MAG XX(UC)// (Parent MAG of the originating MALS)
MWSG XXX(UC)// (Used only if an EAF/WX MF are surveyed)
MWSS XXX(UC)// (Used only if an EAF/WX MF is surveyed)
UNCLAS //N13670//
MSGID/GENADMIN/MALS XX//
SUBJ/SE-4 MOBILE FACILITY (MF) PROGRAM DISPOSITION REQUEST//
REF/A/DOC/NAVAIRINST 13670.1C/26JUN08//
REF/B/DOC/MCO 13670.1/DATE//
REF/C/DOC/COMMARFORXXX/DATE//
List other ref's as applicable, TELCON, etc.
NARR/REFS A THOROUGH C ARE MF INST/ORDERS FOR MANAGEMENT AND ADMINISTRATION OF
MARINE AVIATION MF's.//
POC/(APPLICABLE INFO FOR NAME OF MFC OR DESIGNATED PERSONNEL)//
RMKS/1. IAW REFS A THROUGH C, REQUEST DISPOSITION FOR THE FOLLOWING
MF's/EQUIPMENT:
SER NO CONFIG ISO NO REPLACEMENT REQUIRED Y/N
KZT-XXX ST-XXNMAU XXXXXX X YES
KZT-XXX TR-XXNMAU XXXXXX X NO
2. Full explanation required for requested disposition.//
3. Submit via Chain of Command (i.e. Wing, MarFor etc.)

3 Jan 12

Sample MF Receipt/Transfer/Survey Procedure Checklist**RECEIPT**

- ___ 1. MFC screen MF/LIR for any discrepancies.
Serial #: _____ CONFIG CODE _____
User: _____ RCVD Msg DTG: _____
- ___ 2. PC screen LIR for proper documentation.
- ___ 3. Make appropriate entries on 51 card.
- ___ 4. Add MF & ECU to NALCOMIS.
- ___ 5. Conduct receipt/acceptance inspection IAW AG-360MF-IIN-000.
- ___ 6. Add MF to SESS with ECU serial # in PN block. Add ECU to SESS with MF serial # in PN block.
- ___ 7. Add MF and ECU to PM cycle.
- ___ 8. Annotate acceptance inspection entry in scheduled maintenance block.
- ___ 9. Annotate new PM base date in miscellaneous history block.
- ___ 10. File this form in MF LIR.

TRANSFER/DEPLOYMENT

- ___ 1. PC cut transfer MAF's on MF and ECU.
- ___ 2. Delete from NALCOMIS and SESS.
- ___ 3. Prepare MF and ECU for movement IAW MCO 13670.1.
- ___ 4. MFC do final screening of MF/LIR/KEYS.
- ___ 5. MFC file this form in MF LIR.
- ___ 6. PC retain a copy of this form in the MF binder.
- ___ 7. MFC release Naval message.

SURVEY (Upon NAVAIR Approval for Survey)

- ___ 1. Remove CSC data plate and MF markings.
- ___ 2. Stencil "SURVEYED - NOT FOR EMBARK" in six-inch red letters, centered on both side walls and centered above doors on both ends.
- ___ 3. Stencil DTG of the NAVAIR authorization message in six-inch red letters, centered on both side walls.
- ___ 4. Remove butting kits, walkways, ECU, and fire bottle.
- ___ 5. Delete from NALCOMIS and SESS.
- ___ 6. Dispose of LIR IAW NAVAIR authorization message. Retain LIR Binder for future use.
- ___ 7. Transfer MF to DRMO and forward DD Form 1348-1A to NAVAIR MF Program Office. Retain copy for local records.

Note: This is to be a locally generated checklist to assist in MF program management.

Sample Generator/Ancillary Equipment Rework Request

FM MALS XX(UC)// (Originating MALS)

TO CG XXX MAW ALD(UC)//

CC CMC WASHINGTON DC AVN ASL(UC)//

COMNAVAIRSYSCOM PATUXENT RIVER MD(UC)//

COMMARFORXXX ALD(UC)//

MAG XX (Parent MAG of originating MALS)

UNCLAS //N13670//

MSGID/GENADMIN/MALS XX//

SUBJ/SE-4 MOBILE FACILITY (MF) GENERATOR REWORK REQUEST//

REF/A/DOC/NAVAIRINST 13670.1C/26JUN08//

REF/B/DOC/COMMARFORXXX/DATE//

NARR/REFS A AND B ARE MF INST/ORDERS//

POC/(APPLICABLE INFO FOR NAME OF MFC OR DESIGNATED PERSONNEL)//

RMKS/1. IAW REFS A THRU C, REQ REWORK OF THE FOLLOWING GENERATORS/ANCILLARY EQUIPMENT:

TYPE EQUIP	SER NO	CSP	REMARKS
MEP-807A	100-XXXX	CCSP	ENGINE FROZEN
MEP-809A	200-XXXX	CCSP	NO OUTPUT, BEYOND MAINT CAPABILITIES//

Notes:

1. MAW MFC shall confirm repair is beyond capabilities of parent MALS before forwarding request to NAVAIR 6.7.6.2.

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** AB-02 **																	
000	S3	SCIFXX	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
** Subtotal **			1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
** AB-03 **																	
000	S3	SCIFXX	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
** Subtotal **			1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
** AM-01 **																	
000	05C	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
000	05C	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
000	05C	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** AT-08 **																	
000	S2	118A36	2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
** Subtotal **			2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
** AT-09BM **																	
000	210	118A36	2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
** Subtotal **			2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
** AT-10A **																	
000	210	118A36	2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
** Subtotal **			2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
** AT-11 **																	
ATC	ATC	MACSXX	0	1	1	1	1	0	0	1	1	1	2	1	0	0	0
** Subtotal **			0	1	1	1	1	0	0	1	1	1	2	1	0	0	0
** AT-12 **																	
ATC	ATC	MACSXX	0	1	1	1	1	0	0	1	1	1	2	1	0	0	0
** Subtotal **			0	1	1	1	1	0	0	1	1	1	2	1	0	0	0
** BR-01 **																	
700	71D	118A36	2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
700	71D	118C24	1	0	0	0	0	0	0	0	1	0	0	1	0	0	0
700	71D	1HML27	0	0	0	0	0	1	0	2	0	1	1	0	0	0	0
700	71D	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
700	71D	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
700	71D	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			3	3	2	2	0	1	0	2	3	1	2	1	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS	
** BR-04A **																		
700	71D	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
** Subtotal **			1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
** BR-05B **																		
700	71D	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
** Subtotal **			1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
** CA-01 **																		
600	670	CCSPFW	2	2	0	2	0	0	0	0	0	0	0	0	0	0	0	
AIS	AIS	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0	
AIS	AIS	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0	
** Subtotal **			4	4	2	4	2	2	2	2	2	2	2	2	2	0	0	
** CA-04 **																		
600	670	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
600	670	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
600	670	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	
** Subtotal **			1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
** CA-07A **																		
600	670	CCSPRW	0	0	0	0	0	0	1	0	0	1	1	0	0	0	0	
** Subtotal **			0	0	0	0	0	0	1	0	0	1	1	0	0	0	0	
** CA-08B **																		
600	670	CCSPRW	0	0	0	0	0	0	1	0	0	1	1	0	0	0	0	
** Subtotal **			0	0	0	0	0	0	1	0	0	1	1	0	0	0	0	
** CA-09 **																		
600	670	CCSPRW	0	0	0	0	0	0	1	0	0	1	1	0	0	0	0	
** Subtotal **			0	0	0	0	0	0	1	0	0	1	1	0	0	0	0	
** CL-01 **																		
600	670	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0	
600	670	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0	
600	670	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	
600	670	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			2	2	2	3	2	2	2	2	2	2	2	2	2	1	0	
** CL-02 **																		
600	670	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
600	670	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS	
600	670	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	
** Subtotal **			1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	
** <u>CL-04</u> **																		
600	610	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0	
600	670	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0	
600	610	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0	
600	670	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0	
600	610	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	
600	670	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	
** Subtotal **			4	4	4	4	4	4	4	4	4	4	4	4	4	2	0	
** <u>CL-06</u> **																		
600	670	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
600	670	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
600	670	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	
** Subtotal **			1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
** <u>CL-07</u> **																		
600	670	CCSPFW	4	4	3	4	0	0	0	0	3	0	0	3	0	0	0	
600	670	CCSPRW	0	0	0	0	3	3	4	3	0	4	4	0	3	0	0	
600	670	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	3	0	
** Subtotal **			4	4	3	4	3	3	4	3	3	4	4	3	3	3	3	0
** <u>CL-09</u> **																		
600	670	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0	
600	670	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
600	670	IOSP14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			2	2	2	4	1	1	1	1	2	1	1	2	1	0	0	
** <u>CL-10</u> **																		
600	60A	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
600	670	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
600	60A	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
600	670	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
600	60A	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	
** Subtotal **			2	2	2	2	2	2	2	2	2	2	2	2	2	1	0	
** <u>CR-03</u> **																		
ATC	ATC	MACSXX	0	2	2	2	2	0	0	2	2	2	4	2	0	0	0	
** Subtotal **			0	2	2	2	2	0	0	2	2	2	4	2	0	0	0	

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** CR-04 **																	
600	690	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
600	690	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
600	690	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
** Subtotal **			2	1	0												
** CS-02A **																	
500	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
** Subtotal **			1	0	0												
** CS-03BM **																	
500	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
** Subtotal **			1	0	0												
** CU-01 **																	
000	010	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
000	020	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
400	400	CCSPFW	1	1	1	1	0	0	0	0	0	0	0	0	0	0	0
500	500	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
600	600	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
700	700	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
700	730	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
800	800	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
900	900	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
000	010	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
000	020	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
000	040	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
400	400	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
500	500	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
600	600	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
700	700	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
700	730	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
800	800	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
900	900	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
600	600	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
700	700	PALMXX	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
000	010	TFRS11	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
000	020	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
400	400	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
500	500	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
600	600	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
800	800	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
900	900	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			20	11	11	11	12	11	12	12	10	12	12	10	12	1	0
** <u>CY-01</u> **																	
600	610	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
600	610	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
600	610	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	0	0											
** <u>DP-03</u> **																	
AIS	AIS	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
AIS	AIS	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
** Subtotal **			1	0	0												
** <u>DP-04</u> **																	
AIS	AIS	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
AIS	AIS	CCSPRW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0												
** <u>DP-18A</u> **																	
AIS	AIS	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
AIS	AIS	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
AIS	AIS	IOSP14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
AIS	AIS	IOSP16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
AIS	AIS	IOSP36	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
AIS	AIS	IOSP41	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
** Subtotal **			1	1	1	2	2	1	1	1	1	2	1	2	1	0	0
** <u>EA-01</u> **																	
ZZC	EAF	BEAFFW	1	1	1	2	0	0	0	0	1	0	0	0	0	0	0
ZZC	EAF	BEAFRW	0	0	0	0	1	0	1	0	0	1	1	0	0	0	0
MPS	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
MPS	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
MPS	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
ZZC	EAF	PALMXX	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ZZC	EAF	T30F14	0	0	0	0	0	0	0	0	0	0	0	1	1	0	0
ZZC	EAF	TV8B14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
ZZC	EAF	WGISSX	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	4	2	0	1	0	1	1	1	1	1	0	3
** <u>EA-02</u> **																	

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M15	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
ZZC	EAF	BEAFFW	1	1	1	2	0	0	0	0	1	0	0	0	0	0	0
ZZC	EAF	BEAFRW	0	0	0	0	1	0	1	0	0	1	1	0	0	0	0
MPS	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
MPS	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
MPS	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
ZZC	EAF	PALMXX	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ZZC	EAF	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ZZC	EAF	TV8B14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			3	1	1	4	1	0	1	0	1	1	1	0	0	0	3
** <u>EB-06</u> **																	
600	64B	IOSP12	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
600	64B	IOSP14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	1	0	2	0	0	0	0	0	0	0	0	0	0	0
** <u>EB-07</u> **																	
600	64B	IOSP12	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
600	64B	IOSP14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	1	0	2	0	0	0	0	0	0	0	0	0	0	0
** <u>EB-08</u> **																	
600	64B	IOSP14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
** <u>EB-09</u> **																	
600	64B	IOSP12	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
600	64B	IOSP14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	1	0	2	0	0	0	0	0	0	0	0	0	0	0
** <u>EB-14A</u> **																	
600	64B	IOSP14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** <u>EB-15B</u> **																	
600	64B	IOSP14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** <u>FA-02A</u> **																	
500	520	118A12	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
500	520	118A36	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0
500	520	118C24	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
500	520	318A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS	
500	520	318C24	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	
500	520	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			3	1	0	0	0	0	0	0	2	0	0	1	0	0	0	
** FA-03B **																		
500	520	118A12	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	
500	520	118A36	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0	
500	520	118C24	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
500	520	318A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	
500	520	318C24	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	
500	520	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			3	1	0	0	0	0	0	0	2	0	0	1	0	0	0	
** FC-05 **																		
700	730	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
700	730	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
** Subtotal **			1	0	0													
** FS-01 **																		
S00	CMD	118A36	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
S00	CMD	118C24	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
S00	CMD	130J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0	
S00	CMD	146E12	0	0	0	0	0	0	0	0	0	1	1	0	0	0	0	
S00	CMD	153E16	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0	
S00	CMD	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0	
S00	CMD	1HML27	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0	
S00	CMD	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	
S00	CMD	1V2236	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0	
S00	CMD	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0	
S00	CMD	218A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	
S00	CMD	246E36	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
S00	CMD	253E16	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	
S00	CMD	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	
S00	CMD	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	
S00	CMD	2V2224	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	
S00	CMD	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0	
S00	CMD	318A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	
S00	CMD	318C24	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	
S00	CMD	346E24	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	
S00	CMD	353E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
S00	CMD	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	
S00	CMD	3HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	
S00	CMD	3V2212	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
S00	CMD	3V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	446E24	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	CMD	453E16	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	CMD	4HML27	0	0	0	0	0	0	0	1	0	1	0	0	0	0	0
S00	CMD	553E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	553EXX	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	5HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
400	400	CCSPFW	1	1	1	1	0	0	0	0	0	0	0	0	1	0	0
500	500	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
600	600	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
700	700	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
900	900	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
S00	CMD	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
400	400	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
500	500	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
600	600	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
700	700	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
900	900	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
S00	CMD	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
S00	CMD	F15316	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
S00	CMD	F18A36	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F18C24	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F18R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F1E605	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F1H127	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
S00	CMD	F1V224	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
S00	CMD	F25316	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
S00	CMD	F28A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F28R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F2E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F2H127	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
S00	CMD	F2V224	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
S00	CMD	F30J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
S00	CMD	F34624	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
S00	CMD	F35316	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	CMD	F38A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
S00	CMD	F38C24	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
S00	CMD	F3E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F3H127	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	CMD	F3V224	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	F44624	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	CMD	F45316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	F46FSP	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
S00	CMD	F4H127	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
S00	CMD	F54636	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	F55316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	F5H127	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
MPS	BI	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
** Subtotal **			12	12	11	19	15	11	10	14	9	15	14	5	9	0	1
** GC-01 **																	
600	620	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
600	620	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	1	2	2	0	0	0	0	0	0	0	0	0	0	0
** GM-02A **																	
700	71B	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	1	0	0	0
700	71B	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
700	71B	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			3	2	2	2	1	1	1	1	2	1	1	1	1	0	0
** GM-03B **																	
700	71B	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	1	0	0	0
700	71B	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
700	71B	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			3	2	2	2	1	1	1	1	2	1	1	1	1	0	0
** HC-01 **																	
500	520	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	1	0	0
500	520	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	0	0	0
500	520	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	1	1	0	0						
** HC-02 **																	
500	520	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	1	0	0
500	520	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	0	0	0
500	520	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	1	1	0	0						
** HT-01B **																	
600	69A	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	69A	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0							
** HT-02A **																	

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
600	69A	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	69A	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** <u>HT-03</u> **																	
600	69A	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	69A	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** <u>HY-04A</u> **																	
500	520	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	520	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
500	520	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
500	520	T53E29	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
500	520	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
500	520	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			1	1	1	2	1	1	1	2	1	1	2	1	1	1	0
** <u>HY-05B</u> **																	
500	520	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	520	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
500	520	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
500	520	T53E29	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
500	520	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
500	520	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			1	1	1	2	1	1	1	2	1	1	2	1	1	1	0
** <u>HY-06C</u> **																	
500	520	1V2236	0	0	0	0	0	1	2	0	0	1	1	0	0	0	0
500	520	3V2212	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0
500	520	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
500	520	TV2226	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	1	1	3	0	0	1	1	0	1	1	0
** <u>JU-01</u> **																	
000	000	118A12	0	0	0	0	0	0	0	0	0	0	0	6	0	0	0
000	000	118A36	8	8	0	0	0	0	0	0	8	0	0	0	0	0	0
S00	SO	118A36	4	0	0	0	0	0	0	0	0	0	0	0	0	0	0
000	000	118C24	6	0	0	0	0	0	0	0	6	0	0	0	0	0	0
S00	SO	118C24	4	0	0	0	0	0	0	0	0	0	0	0	0	0	0
000	000	130J12	2	0	0	2	0	0	0	0	0	2	0	0	0	0	0
S00	SO	130J12	2	0	0	2	0	0	0	0	0	2	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
000	000	130T12	0	0	0	0	0	0	0	0	0	0	0	3	3	0	0
S00	SO	146E12	0	0	0	0	0	0	0	0	0	2	2	0	0	0	0
000	000	146E36	0	0	0	0	2	0	0	0	0	2	2	0	0	0	0
000	000	153E16	0	0	0	0	1	1	0	1	0	1	0	0	0	0	0
S00	SO	153E16	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
000	000	1E6B05	0	3	0	3	0	0	0	0	0	0	0	0	0	0	0
S00	SO	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
000	000	1HML27	0	0	0	0	0	2	0	2	0	2	2	0	0	0	0
S00	SO	1HML27	0	0	0	0	0	4	0	4	0	0	0	0	0	0	0
S00	SO	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	4	0	0
000	000	1RS53E	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
S00	SO	1V2236	0	0	0	0	0	4	4	0	0	0	0	0	0	0	0
000	000	1V8R14	0	4	4	4	0	0	0	0	0	0	0	0	0	0	0
S00	SO	1V8R14	0	2	2	2	0	0	0	0	0	0	0	0	0	0	0
000	000	218A36	8	0	0	0	0	0	0	0	8	0	0	0	0	0	0
S00	SO	218A36	0	4	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	SO	246E36	0	0	0	0	4	0	0	0	0	0	0	0	0	0	0
000	000	253E16	0	0	0	0	1	0	0	1	0	0	0	0	0	0	0
S00	SO	253E16	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
000	000	2E6B05	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
S00	SO	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
000	000	2HML27	0	0	0	0	0	0	0	2	0	0	2	0	0	0	0
S00	SO	2HML27	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
S00	SO	2V2224	0	0	0	0	0	0	4	0	0	0	0	0	0	0	0
000	000	2V8R14	0	0	4	4	0	0	0	0	0	0	0	0	0	0	0
S00	SO	2V8R14	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
S00	SO	318A36	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
S00	SO	318C24	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
S00	SO	346E24	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
S00	SO	353E16	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
000	000	3E6B05	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
S00	SO	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	SO	3HML27	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
S00	SO	3V2212	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	SO	3V8R14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
S00	SO	446E24	0	0	0	0	0	0	0	0	0	4	0	0	0	0	0
S00	SO	453E16	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
S00	SO	4HML27	0	0	0	0	0	0	0	4	0	4	0	0	0	0	0
S00	SO	553E16	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	SO	553EXX	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	SO	5HML27	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
000	000	CCSPFW	12	12	12	12	0	0	0	0	12	0	0	12	0	0	0
600	600	CCSPFW	13	13	13	13	0	0	0	0	13	0	0	14	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
700	700	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
S00	SO	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
000	000	CCSPRW	0	0	0	0	12	12	12	12	0	12	12	0	13	0	0
600	600	CCSPRW	0	0	0	0	12	12	12	12	0	12	12	0	10	0	0
700	700	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
S00	SO	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
000	000	F1130T	0	0	0	0	0	0	0	0	0	0	0	1	1	0	0
000	000	F15316	0	0	0	0	1	1	0	1	0	0	0	0	0	0	0
S00	SO	F15316	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
000	000	F18A36	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0
S00	SO	F18A36	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
000	000	F18C24	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0
S00	SO	F18C24	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
000	000	F18R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	SO	F18R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
000	000	F1E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	SO	F1E605	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	SO	F1H127	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
S00	SO	F1V224	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
000	000	F25316	0	0	0	0	1	0	0	1	0	0	0	0	0	0	0
S00	SO	F25316	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
000	000	F28A36	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0
S00	SO	F28A36	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
000	000	F28R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	SO	F28R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
000	000	F2E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	SO	F2E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	SO	F2H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	SO	F2V224	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
000	000	F30J12	1	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	SO	F30J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
S00	SO	F34624	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	SO	F35316	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	SO	F38A36	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
S00	SO	F38C24	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
000	000	F3E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	SO	F3E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	SO	F3H127	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
S00	SO	F3V224	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	SO	F44624	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
S00	SO	F45316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	SO	F46FSP	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
S00	SO	F4H127	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
S00	SO	F54636	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	SO	F55316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	SO	F5H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
600	600	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	5	0
600	600	IOSP11	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	IOSP13	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0
600	600	IOSP14	0	0	0	6	0	0	0	0	0	0	0	0	0	0	0
600	600	IOSP31	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
ATC	ATC	MACSXX	0	1	1	2	1	0	0	1	1	1	2	1	0	0	0
MPS	BI	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
700	700	PALMXX	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	T53E29	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
000	000	TFRS11	10	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	TFRS11	7	0	0	0	0	0	0	0	0	0	0	0	0	0	0
700	700	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
000	000	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
600	600	TV8B14	0	0	0	4	0	0	0	0	0	0	0	0	0	0	0
600	600	WGISSX	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
** Subtotal **			92	55	46	83	52	46	39	55	67	55	60	40	37	5	1
** <u>JU-09</u> **																	
600	600	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
600	600	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
600	600	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	1	0	3	0	0	0	0	0	0	0	0	0	0	0
** <u>JU-10</u> **																	
600	600	1E6B05	0	2	0	2	0	0	0	0	0	0	0	0	0	0	0
600	600	2E6B05	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
600	600	3E6B05	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	2	0	6	0	0	0	0	0	0	0	0	0	0	0
** <u>JU-31</u> **																	
000	S3	SCIFXX	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
** Subtotal **			1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
** <u>JU-32</u> **																	
000	S3	SCIFXX	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
** Subtotal **			1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
** <u>KA-01A</u> **																	

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
600	690	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	690	IOSP31	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	690	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** <u>KA-02B</u> **																	
600	690	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	690	IOSP31	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	690	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** <u>KA-03A</u> **																	
600	610	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	610	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** <u>KA-04B</u> **																	
600	610	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	610	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** <u>KA-05A</u> **																	
600	630	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	630	IOSP31	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	630	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	630	TV8B14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** <u>KA-06B</u> **																	
600	630	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	630	IOSP31	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	630	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	630	TV8B14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** <u>KA-07A</u> **																	
600	640	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	640	IOSP11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	640	IOSP12	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	640	IOSP31	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	640	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	640	TV8B14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** <u>KA-08B</u> **																	
600	640	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	640	IOSP11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	640	IOSP12	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	640	IOSP31	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	640	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	640	TV8B14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** <u>KA-18A</u> **																	
600	600	1HML27	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
600	600	1V2236	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
600	600	CCSPFW	7	7	7	7	0	0	0	0	9	0	0	3	0	0	0
600	600	CCSPRW	0	0	0	0	4	3	4	4	0	4	4	0	3	0	0
600	600	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	2	0
600	600	IOSP11	6	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	IOSP12	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	IOSP14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
600	600	IOSP31	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
600	600	IOSP49	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
600	600	TFRS11	6	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	TV2226	0	0	0	0	0	0	4	0	0	0	0	0	0	0	0
600	600	TV8B14	0	0	0	5	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			19	9	7	14	6	3	8	4	13	4	7	3	4	2	0
** <u>KA-19A</u> **																	
600	630	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	1	0	0	0
600	630	IOSP11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	630	IOSP14	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
600	630	IOSP31	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
600	630	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	630	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			4	2	2	6	0	0	0	0	3	0	0	1	0	0	0
** <u>KA-20B</u> **																	
600	630	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	1	0	0	0
600	630	IOSP11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	630	IOSP14	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
600	630	IOSP31	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
600	630	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	630	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** Subtotal **			4	2	2	6	0	0	0	0	3	0	0	1	0	0	0
** <u>KA-31</u> **																	
600	600	118A12	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
600	600	118A36	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	1E6B05	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
600	600	1HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
600	600	1V2236	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	1V8R14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	218A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	2E6B05	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
600	600	2V2224	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	2V8R14	0	0	3	1	0	0	0	0	0	0	0	0	0	0	0
600	600	318A36	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
600	600	3V2212	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
600	600	CCSPFW	3	3	3	3	0	0	0	0	3	0	0	3	0	0	0
600	600	CCSPRW	0	0	0	0	3	3	3	3	0	3	3	0	3	0	0
600	600	IOSP11	11	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	IOSP12	0	11	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	IOSP13	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	IOSP14	0	0	0	4	0	0	0	0	0	0	0	0	0	0	0
600	600	IOSP31	0	0	0	0	0	0	0	0	9	0	0	0	0	0	0
600	600	IOSP41	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	600	TV2226	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
600	600	TV8B14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			16	15	6	14	4	3	4	3	16	3	5	4	3	0	0
** <u>LA-01</u> **																	
600	620	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
900	940	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
600	620	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
900	940	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
600	620	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
MPS	BI	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
MPS	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
MPS	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
MPS	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
600	620	T53E29	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
600	620	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	620	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
600	620	WGISSX	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
** Subtotal **			3	2	2	3	3	2	2	3	2	2	2	2	2	1	7

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** MC-01 **																	
000	020	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
600	670	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
700	700	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
900	900	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
000	020	CCSPRW	0	0	0	0	2	1	2	2	0	2	2	0	2	0	0
600	670	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
700	700	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
900	900	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
000	020	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
000	020	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			6	5	5	6	5	4	5	5	5	5	5	5	5	0	0
** MM-01 **																	
500	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
500	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** MM-02 **																	
500	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	1	0	0
500	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	0	0	0
500	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** MM-03 **																	
500	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
500	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** MM-04 **																	
500	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
500	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** NB-03 **																	
600	620	1HML09	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
600	620	1HML27	0	0	0	0	0	1	0	2	0	2	0	0	0	0	0
600	620	2HML09	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
600	620	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS	
600	620	3HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	
600	620	4HML27	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0	
600	620	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	
MPS	BI	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	
MPS	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	
MPS	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	
MPS	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	
600	620	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	
** Subtotal **			0	0	0	0	0	1	0	4	0	2	3	0	2	1	7	
** <u>NT-06</u> **																		
500	530	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
500	530	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
500	530	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			2	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** <u>NT-07</u> **																		
500	530	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
500	530	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
500	530	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			2	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** <u>NT-08</u> **																		
500	530	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
500	530	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
500	530	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			2	1	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** <u>NV-01</u> **																		
600	610	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
600	610	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
** Subtotal **			1	1	1	1	1	1	1	1	1	1	1	1	1	0	0	0
** <u>PM-01</u> **																		
600	64C	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0	
600	64C	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	
600	64C	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			0	1	0	3	0	0	0	0	0	0	0	0	0	0	0	0
** <u>PM-02</u> **																		
600	64C	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			0	1	1	1	0	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS	
** <u>PP-01</u> **																		
400	410	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
** Subtotal **			0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
** <u>PP-03A</u> **																		
400	440	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
** Subtotal **			0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
** <u>PP-04BM</u> **																		
400	440	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
** Subtotal **			0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
** <u>RR-02</u> **																		
800	810	130J12	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	
800	810	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
800	810	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			2	1	1	1	0	0	0	0	1	1	0	1	0	0	0	
** <u>RR-03</u> **																		
800	810	130J12	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	
800	810	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
** Subtotal **			1	1	1	1	0	0	0	0	1	1	0	1	0	0	0	
** <u>RR-04A</u> **																		
800	810	1V2236	0	0	0	0	0	0	2	0	0	1	1	0	0	0	0	
800	810	3V2212	0	0	0	0	1	1	0	0	0	0	0	0	1	0	0	
800	810	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	
800	810	TV2226	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	
** Subtotal **			0	0	0	0	1	1	3	0	0	1	1	0	1	1	0	
** <u>RR-05B</u> **																		
800	810	1V2236	0	0	0	0	0	0	2	0	0	1	1	0	0	0	0	
800	810	3V2212	0	0	0	0	1	1	0	0	0	0	0	0	1	0	0	
800	810	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	
800	810	TV2226	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	
** Subtotal **			0	0	0	0	1	1	3	0	0	1	1	0	1	1	0	
** <u>RT-10</u> **																		
600	64B	1E6B05	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
600	64B	2E6B05	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** RT-11A **																	
600	64B	1E6B05	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	64B	2E6B05	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** RT-12B **																	
600	64B	1E6B05	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	64B	2E6B05	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** SE-01 **																	
800	810	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
800	810	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
800	810	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	0	1	1	1	1	1	1	1	0	0
** SE-02B **																	
800	810	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
** Subtotal **			0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
** SE-03C **																	
800	810	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
** Subtotal **			0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
** SE-04B **																	
800	810	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
** Subtotal **			0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
** SE-05 **																	
800	810	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
** Subtotal **			1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
** SE-06C **																	
800	810	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
** Subtotal **			1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
** SH-03 **																	
600	64C	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** SH-04 **																	

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
600	64C	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** <u>SH-06</u> **																	
600	64C	130J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
600	64C	130T12	0	0	0	0	0	0	0	0	0	0	0	1	1	0	0
600	640	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	1	0	0
600	640	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
** Subtotal **			1	0	0	1	2	2	2	2	0	3	2	1	2	1	0
** <u>SM-04B</u> **																	
500	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
500	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** <u>SM-05A</u> **																	
500	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
500	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** <u>SM-06B</u> **																	
500	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
500	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** <u>SM-07A</u> **																	
500	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
500	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** <u>SP-04</u> **																	
500	520	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
** <u>ST-01</u> **																	
600	610	118A36	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
600	620	118A36	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
600	64D	118A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
600	610	118C24	1	0	0	0	0	0	0	0	1	0	0	1	0	0	0
600	620	118C24	1	0	0	0	0	0	0	0	1	0	0	1	0	0	0
600	610	130T12	0	0	0	0	0	0	0	0	0	0	0	3	3	0	0
600	620	130T12	0	0	0	0	0	0	0	0	0	0	0	1	1	0	0
600	620	146E36	0	0	0	0	1	0	0	0	0	1	1	0	0	0	0
600	620	153E16	0	0	0	0	1	1	0	2	0	1	0	0	0	0	0
600	610	1E6B05	0	2	0	2	0	0	0	0	0	0	0	0	0	0	0
600	620	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
600	620	1HML27	0	0	0	0	0	1	0	2	0	1	1	0	0	0	0
600	620	1RS53E	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
600	610	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
600	620	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
600	620	253E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
600	610	2E6B05	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
600	620	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
600	620	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
600	610	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
600	620	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
600	610	3E6B05	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
600	620	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
500	520	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
600	610	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
600	620	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
600	62B	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
600	64C	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
600	64D	CCSPFW	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
600	690	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	520	CCSPRW	0	0	0	0	0	0	0	0	0	0	0	0	5	0	0
600	610	CCSPRW	0	0	0	0	3	3	3	3	0	3	3	0	3	0	0
600	620	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
600	62B	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
600	640	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	2	0	0
600	690	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
600	610	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
600	620	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	2	0
600	690	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
600	610	T53E29	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
600	620	T53E29	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
500	520	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	610	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	620	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	62B	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	64C	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0

3 Jan 12

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
600	610	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
600	620	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
500	520	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
600	610	TV8B14	0	0	0	6	0	0	0	0	0	0	0	0	0	0	0
600	620	TV8B14	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			16	16	11	30	10	9	7	14	11	10	12	13	18	4	0
** <u>SU-01</u> **																	
S00	CMD	118A36	3	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	118C24	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	130J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
S00	RMD	146E12	0	0	0	0	0	0	0	0	0	1	1	0	0	0	0
S00	RMD	153E16	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
S00	RMD	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	1HML27	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
S00	RMD	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
S00	RMD	1V2236	0	0	0	0	0	3	3	0	0	0	0	0	0	0	0
S00	RMD	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	218A36	0	3	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	246E36	0	0	0	0	3	0	0	0	0	0	0	0	0	0	0
S00	RMD	253E16	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
S00	RMD	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	2HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	RMD	2V2224	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
S00	RMD	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	318A36	0	0	0	0	0	0	0	0	3	0	0	0	0	0	0
S00	RMD	318C24	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
S00	RMD	346E24	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	RMD	353E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	3HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	RMD	3V2212	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	3V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	446E24	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
S00	RMD	453E16	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	RMD	4HML27	0	0	0	0	0	0	0	2	0	2	0	0	0	0	0
S00	RMD	553E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	553EXX	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	5HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
000	05C	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
000	05D	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
600	600	CCSPFW	4	4	4	4	0	0	0	0	4	0	0	4	0	0	0
S00	RMD	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
000	05C	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
000	05D	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
600	600	CCSPRW	0	0	0	0	4	4	4	4	0	4	4	0	4	0	0
600	640	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
S00	RMD	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
S00	RMD	F15316	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
S00	RMD	F18A36	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F18C24	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F18R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F1E605	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F1H127	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
S00	RMD	F1V224	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
S00	RMD	F25316	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
S00	RMD	F28A36	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F28R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F2E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F2H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	RMD	F2V224	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
S00	RMD	F30J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
S00	RMD	F34624	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	RMD	F35316	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	RMD	F38A36	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
S00	RMD	F38C24	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
S00	RMD	F3E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F3H127	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
S00	RMD	F3V224	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	RMD	F44624	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
S00	RMD	F45316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	F46FSP	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
S00	RMD	F4H127	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
S00	RMD	F54636	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	F55316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	F5H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
600	600	IOSP14	0	0	0	4	0	0	0	0	0	0	0	0	0	0	0
600	64B	IOSP14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
000	05C	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
000	05C	TV8B14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			19	16	12	27	20	18	17	20	16	21	23	7	12	0	0
** <u>SU-02</u> **																	
S00	CMD	118A36	3	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	118C24	3	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	130J12	2	0	0	2	0	0	0	0	0	2	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
S00	CMD	146E12	0	0	0	0	0	0	0	0	0	2	2	0	0	0	0
S00	CMD	153E16	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
S00	CMD	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	1HML27	0	0	0	0	0	3	0	3	0	0	0	0	0	0	0
S00	CMD	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	3	0	0
S00	CMD	1V2236	0	0	0	0	0	3	3	0	0	0	0	0	0	0	0
S00	CMD	1V8R14	0	2	2	2	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	218A36	0	3	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	246E36	0	0	0	0	3	0	0	0	0	0	0	0	0	0	0
S00	CMD	253E16	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
S00	CMD	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	2HML27	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
S00	CMD	2V2224	0	0	0	0	0	0	3	0	0	0	0	0	0	0	0
S00	CMD	2V8R14	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	318A36	0	0	0	0	0	0	0	0	3	0	0	0	0	0	0
S00	CMD	318C24	0	0	0	0	0	0	0	0	3	0	0	0	0	0	0
S00	CMD	346E24	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
S00	CMD	353E16	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	CMD	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	3HML27	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
S00	CMD	3V2212	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	CMD	3V8R14	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	446E24	0	0	0	0	0	0	0	0	0	3	0	0	0	0	0
S00	CMD	453E16	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
S00	CMD	4HML27	0	0	0	0	0	0	0	3	0	3	0	0	0	0	0
S00	CMD	553E16	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	CMD	553EXX	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	CMD	5HML27	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
S00	CMD	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
S00	CMD	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
S00	CMD	F18A36	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F18C24	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F18R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F1E605	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F1H127	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
S00	CMD	F1V224	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
S00	CMD	F28A36	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F28R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F2E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F2H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	CMD	F2V224	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
S00	CMD	F30J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
S00	CMD	F34624	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
S00	CMD	F35316	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	CMD	F38A36	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
S00	CMD	F38C24	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
S00	CMD	F3E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F3H127	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
S00	CMD	F3V224	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	CMD	F44624	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
S00	CMD	F45316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	F46FSP	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
S00	CMD	F4H127	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
S00	CMD	F54636	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	F55316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	F5H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
** Subtotal **			14	11	9	18	17	13	11	15	11	19	21	1	6	0	0
** <u>SU-03</u> **																	
600	630	118A36	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
600	630	118C24	1	0	0	0	0	0	0	0	1	0	0	1	0	0	0
S00	CMD	130J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
S00	CMD	146E12	0	0	0	0	0	0	0	0	0	1	1	0	0	0	0
S00	CMD	153E16	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
S00	CMD	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	253E16	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
S00	CMD	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	353E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	3V2212	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	3V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	453E16	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	CMD	553E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	553EXX	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
ZZC	EAF	BEAFFW	1	1	1	2	0	0	0	0	1	0	0	0	0	0	0
ZZC	EAF	BEAFRW	0	0	0	0	1	0	1	0	0	1	1	0	0	0	0
700	700	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
900	900	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
900	990	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
AIS	AIS	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
400	410	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
700	700	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
900	900	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
900	990	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
AIS	AIS	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
AIS	AIS	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
600	600	IOSP14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
600	670	IOSP14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
ATC	ATC	MACSXX	0	1	1	2	1	0	0	1	1	1	2	0	0	0	0
MPS	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
MPS	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
MPS	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
** Subtotal **			8	8	9	15	11	1	6	8	8	10	9	5	5	1	6
** <u>SU-04</u> **																	
S00	SRD	1HML27	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
** <u>SU-05</u> **																	
S00	CMD	118A36	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	118A36	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	SAD	118A36	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	SRD	118A36	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	SAD	118C24	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	SRD	118C24	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	SAD	1HML27	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
S00	SAD	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
S00	SRD	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
S00	CMD	1V2236	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
S00	RMD	1V2236	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
S00	SAD	1V2236	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
S00	SRD	1V2236	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
S00	CMD	218A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	218A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	SAD	218A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	SRD	218A36	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	246E36	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	246E36	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	SAD	246E36	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	SRD	246E36	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	SAD	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
S00	SRD	2HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	SAD	2V2224	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
S00	SRD	2V2224	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
S00	CMD	318A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
S00	RMD	318A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
S00	SAD	318A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
S00	SRD	318A36	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
S00	SAD	318C24	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
S00	SRD	318C24	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
S00	SAD	346E24	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
S00	SRD	346E24	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	SAD	3HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
S00	SRD	3HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	SAD	446E24	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	SRD	446E24	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
S00	SAD	4HML27	0	0	0	0	0	0	0	1	0	1	0	0	0	0	0
S00	SRD	4HML27	0	0	0	0	0	0	0	2	0	2	0	0	0	0	0
S00	SAD	5HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
S00	SRD	5HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
900	990	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
900	990	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
900	990	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
900	990	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			10	6	1	1	6	7	9	5	9	7	13	1	4	1	0
** <u>SU-08</u> **																	
000	05A	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
000	05A	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
** Subtotal **			1	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** <u>SU-12</u> **																	
S00	CMD	118A36	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	118A36	4	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	118C24	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	118C24	4	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	130J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
S00	RMD	130J12	2	0	0	2	0	0	0	0	0	2	0	0	0	0	0
S00	CMD	146E12	0	0	0	0	0	0	0	0	0	1	1	0	0	0	0
S00	RMD	146E12	0	0	0	0	0	0	0	0	0	2	2	0	0	0	0
S00	CMD	153E16	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
S00	RMD	153E16	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
S00	CMD	1E6B05	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	1HML27	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
S00	RMD	1HML27	0	0	0	0	0	4	0	4	0	0	0	0	0	0	0
S00	CMD	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
S00	RMD	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	4	0	0
S00	CMD	1V2236	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
S00	RMD	1V2236	0	0	0	0	0	4	4	0	0	0	0	0	0	0	0
S00	CMD	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	1V8R14	0	2	2	2	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
S00	CMD	218A36	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	218A36	0	4	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	246E36	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	RMD	246E36	0	0	0	0	4	0	0	0	0	0	0	0	0	0	0
S00	CMD	253E16	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
S00	RMD	253E16	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
S00	RMD	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	2HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	RMD	2HML27	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
S00	CMD	2V2224	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
S00	RMD	2V2224	0	0	0	0	0	0	4	0	0	0	0	0	0	0	0
S00	CMD	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	2V8R14	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	318A36	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
S00	RMD	318A36	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
S00	CMD	318C24	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
S00	RMD	318C24	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
S00	CMD	346E24	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	RMD	346E24	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
S00	CMD	353E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	353E16	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	RMD	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	3HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	RMD	3HML27	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
S00	CMD	3V2212	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	3V2212	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	CMD	3V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	3V8R14	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	446E24	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
S00	RMD	446E24	0	0	0	0	0	0	0	0	0	4	0	0	0	0	0
S00	CMD	453E16	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	RMD	453E16	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
S00	CMD	4HML27	0	0	0	0	0	0	0	2	0	2	0	0	0	0	0
S00	RMD	4HML27	0	0	0	0	0	0	0	4	0	4	0	0	0	0	0
S00	CMD	553E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	553E16	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	CMD	553EXX	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	553EXX	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	CMD	5HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	RMD	5HML27	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
000	05A	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
700	71D	CCSPFW	4	4	4	4	0	0	0	0	4	0	0	4	0	0	0
S00	CMD	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
S00	RMD	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
000	05A	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
400	440	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
700	71D	CCSPRW	0	0	0	0	2	0	2	2	0	2	2	0	2	0	0
S00	CMD	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
S00	RMD	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
S00	CMD	F15316	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
S00	RMD	F15316	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
S00	CMD	F18A36	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F18A36	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F18C24	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F18C24	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F18R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F18R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F1E605	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F1H127	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
S00	RMD	F1H127	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
S00	CMD	F1V224	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
S00	RMD	F1V224	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
S00	CMD	F25316	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
S00	RMD	F25316	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
S00	CMD	F28A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F28A36	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F28R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F28R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
S00	RMD	F2E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F2H127	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
S00	RMD	F2H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	CMD	F2V224	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
S00	RMD	F2V224	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
S00	CMD	F30J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
S00	RMD	F30J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
S00	CMD	F34624	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
S00	RMD	F34624	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
S00	CMD	F35316	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	RMD	F35316	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	CMD	F38A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
S00	RMD	F38A36	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
S00	CMD	F38C24	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
S00	RMD	F38C24	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
S00	RMD	F3E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
S00	CMD	F3H127	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	RMD	F3H127	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
S00	CMD	F3V224	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	F3V224	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
S00	CMD	F44624	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
S00	RMD	F44624	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
S00	CMD	F45316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	F45316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	F46FSP	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
S00	RMD	F46FSP	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
S00	CMD	F4H127	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
S00	RMD	F4H127	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
S00	CMD	F54636	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	F54636	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	F55316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	RMD	F55316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
S00	CMD	F5H127	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
S00	RMD	F5H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
600	670	IOSP14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
MPS	BI	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	8
MPS	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	12
MPS	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	12
MPS	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	12
000	05A	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			31	24	20	32	33	26	24	36	25	37	42	7	15	0	44
** <u>SW-02</u> **																	
800	820	118A36	1	1	0	0	0	0	0	0	1	0	0	1	0	0	0
800	820	118C24	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
800	820	1HML27	0	0	0	0	0	0	0	2	0	0	1	0	2	0	0
800	820	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
800	820	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
** Subtotal **			3	2	0	0	0	0	0	2	2	0	2	1	2	0	0
** <u>TB-01</u> **																	
500	520	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	520	CCSPRW	0	0	0	0	1	1	0	2	0	1	1	0	1	0	0
500	520	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	1	0	2	1	1	1	1	1	0	0
** <u>TB-02</u> **																	
500	520	1V2236	0	0	0	0	0	1	2	0	0	1	1	0	0	0	0
500	520	3V2212	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0
500	520	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
500	520	TV2226	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** Subtotal **			0	0	0	0	1	1	3	0	0	1	1	0	1	1	0
** <u>TL-01</u> **																	
000	040	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
600	670	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
000	040	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
600	670	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
600	670	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
** Subtotal **			2	2	2	2	2	2	2	2	2	2	2	2	2	1	0
** <u>TR-01</u> **																	
400	400	118A12	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
400	400	118A36	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0
400	400	118C24	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
400	400	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
400	400	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
400	400	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
000	05D	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	500	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
900	900	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
000	05D	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
400	440	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
500	500	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
900	900	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
000	05D	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
900	900	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			7	5	3	6	4	4	4	4	3	4	4	4	4	0	0
** <u>TT-02</u> **																	
600	620	1HML27	0	0	0	0	0	1	0	2	0	1	1	0	1	0	0
600	620	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
** Subtotal **			0	0	0	0	0	1	0	2	0	1	2	0	1	0	0
** <u>TT-03A</u> **																	
600	620	1HML27	0	0	0	0	0	1	0	2	0	1	1	0	1	0	0
600	620	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
** Subtotal **			0	0	0	0	0	1	0	2	0	1	2	0	1	0	0
** <u>TT-04B</u> **																	
600	620	1HML27	0	0	0	0	0	1	0	2	0	1	1	0	1	0	0
600	620	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
** Subtotal **			0	0	0	0	0	1	0	2	0	1	2	0	1	0	0

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** TW-05A **																	
500	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
MPS	BI	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
MPS	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
MPS	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
MPS	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
** Subtotal **			1	0	7												
** TW-06B **																	
500	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
MPS	BI	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
MPS	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
MPS	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
MPS	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
** Subtotal **			1	0	7												
** VD-05A **																	
600	620	CCSPRW	0	0	0	0	0	1	1	1	0	1	1	0	0	0	0
600	620	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
** Subtotal **			0	0	0	0	0	1	1	1	0	1	2	0	0	0	0
** VD-06B **																	
600	620	CCSPRW	0	0	0	0	0	1	1	1	0	1	1	0	0	0	0
600	620	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
** Subtotal **			0	0	0	0	0	1	1	1	0	1	2	0	0	0	0
** VD-07A **																	
600	620	130T12	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
600	620	153E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
600	620	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
600	620	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
600	620	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
600	620	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	2	1	0	0	0	1	0	0	1	1	1	0
** VD-08B **																	
600	620	130T12	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
600	620	153E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
600	620	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
600	620	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0

3 Jan 12

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS	
600	620	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
600	620	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			2	1	1	2	1	0	0	0	1	0	0	1	1	1	0	
** <u>WC-02</u> **																		
000	030	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0	
000	040	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0	
000	030	CCSPRW	0	0	0	0	2	0	2	2	0	2	2	0	2	0	0	
000	040	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0	
000	030	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
000	040	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			6	4	4	4	4	2	4	4	4	4	4	4	4	0	0	
** <u>WC-08</u> **																		
900	910	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
900	930	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
900	940	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
900	910	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
900	930	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
900	940	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
900	910	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
900	930	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
900	940	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			6	3	3	3	3	3	3	3	3	3	3	3	3	0	0	
** <u>WC-12A</u> **																		
900	990	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
900	990	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
900	990	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	
** Subtotal **			1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
** <u>WC-13BM</u> **																		
900	990	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0	
900	990	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0	
900	990	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	
** Subtotal **			1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0
** <u>WJ-06</u> **																		
ATC	ATC	MACSXX	0	1	2	2	1	0	0	1	1	1	1	1	1	0	0	
** Subtotal **			0	1	2	2	1	0	0	1	1	1	1	1	1	0	0	
** <u>WL-04A</u> **																		

USMC MF TBA by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
500	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
500	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** <u>WL-05A</u> **																	
500	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
500	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
500	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			2	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** <u>WR-01</u> **																	
600	690	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
600	690	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	0	0	0
** Subtotal **			1	1	1	1	1	1	1	1	1	1	1	1	0	0	0
Total			415	310	245	416	284	239	248	295	311	302	338	193	221	39	86

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** 118A12 **																	
FA-02A	500	520	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
FA-03B	500	520	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
JU-01	000	000	0	0	0	0	0	0	0	0	0	0	0	6	0	0	0
KA-31	600	600	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
TR-01	400	400	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	10	0	0	0
** 118A36 **																	
AT-08	000	S2	2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
AT-09BM	000	210	2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
AT-10A	000	210	2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
BR-01	700	71D	2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
FA-02A	500	520	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0
FA-03B	500	520	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0
FS-01	S00	CMD	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	4	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	8	8	0	0	0	0	0	0	8	0	0	0	0	0	0
KA-31	600	600	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	610	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
ST-01	600	620	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
ST-01	600	64D	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-01	S00	CMD	3	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	3	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-03	600	630	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-05	S00	CMD	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	S00	RMD	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	S00	SAD	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	S00	SRD	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	4	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SW-02	800	820	1	1	0	0	0	0	0	0	1	0	0	1	0	0	0
TR-01	400	400	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			47	24	0	0	0	0	0	0	20	0	0	1	0	0	0
** 118C24 **																	
BR-01	700	71D	1	0	0	0	0	0	0	0	1	0	0	1	0	0	0
FA-02A	500	520	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FA-03B	500	520	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FS-01	S00	CMD	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	4	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	6	0	0	0	0	0	0	0	6	0	0	0	0	0	0
ST-01	600	610	1	0	0	0	0	0	0	0	1	0	0	1	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
ST-01	600	620	1	0	0	0	0	0	0	0	1	0	0	1	0	0	0
SU-01	S00	RMD	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	3	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-03	600	630	1	0	0	0	0	0	0	0	1	0	0	1	0	0	0
SU-05	S00	SAD	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	S00	SRD	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	4	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SW-02	800	820	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
TR-01	400	400	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			33	1	0	0	0	0	0	0	11	0	0	4	0	0	0
** <u>130J12</u> **																	
FS-01	S00	CMD	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
JU-01	S00	SO	2	0	0	2	0	0	0	0	0	2	0	0	0	0	0
JU-01	000	000	2	0	0	2	0	0	0	0	0	2	0	0	0	0	0
RR-02	800	810	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
RR-03	800	810	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SH-06	600	64C	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SU-01	S00	RMD	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SU-02	S00	CMD	2	0	0	2	0	0	0	0	0	2	0	0	0	0	0
SU-03	S00	CMD	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SU-12	S00	CMD	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SU-12	S00	RMD	2	0	0	2	0	0	0	0	0	2	0	0	0	0	0
** Subtotal **			13	0	0	13	0	0	0	0	0	15	0	0	0	0	0
** <u>130T12</u> **																	
JU-01	000	000	0	0	0	0	0	0	0	0	0	0	0	3	3	0	0
SH-06	600	64C	0	0	0	0	0	0	0	0	0	0	0	1	1	0	0
ST-01	600	610	0	0	0	0	0	0	0	0	0	0	0	3	3	0	0
ST-01	600	620	0	0	0	0	0	0	0	0	0	0	0	1	1	0	0
VD-07A	600	620	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
VD-08B	600	620	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	8	10	0	0
** <u>146E12</u> **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	1	1	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	2	2	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	1	1	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	2	2	0	0	0	0
SU-03	S00	CMD	0	0	0	0	0	0	0	0	0	1	1	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	1	1	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	2	2	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	10	10	0	0	0	0

3 Jan 12

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** 146E36 **																	
JU-01	000	000	0	0	0	0	2	0	0	0	0	2	2	0	0	0	0
ST-01	600	620	0	0	0	0	1	0	0	0	0	1	1	0	0	0	0
** Subtotal **			0	0	0	0	3	0	0	0	0	3	3	0	0	0	0
** 153E16 **																	
FS-01	S00	CMD	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
JU-01	000	000	0	0	0	0	1	1	0	1	0	1	0	0	0	0	0
ST-01	600	620	0	0	0	0	1	1	0	2	0	1	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-03	S00	CMD	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
VD-07A	600	620	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
VD-08B	600	620	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	4	12	0	13	0	2	0	0	0	0	0
** 1E6B05 **																	
FS-01	S00	CMD	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	0	3	0	3	0	0	0	0	0	0	0	0	0	0	0
JU-09	600	600	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-10	600	600	0	2	0	2	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	600	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
PM-01	600	64C	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
RT-10	600	64B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RT-11A	600	64B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RT-12B	600	64B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	610	0	2	0	2	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	620	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
TR-01	400	400	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	17	0	19	0	0	0	0	0	0	0	0	0	0	0
** 1HML09 **																	
NB-03	600	620	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	1	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** 1HML27 **																	
BR-01	700	71D	0	0	0	0	0	1	0	2	0	1	1	0	0	0	0
FS-01	S00	CMD	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	4	0	4	0	0	0	0	0	0	0
JU-01	000	000	0	0	0	0	0	2	0	2	0	2	2	0	0	0	0
KA-18A	600	600	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
KA-31	600	600	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
NB-03	600	620	0	0	0	0	0	1	0	2	0	2	0	0	0	0	0
ST-01	600	620	0	0	0	0	0	1	0	2	0	1	1	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	3	0	3	0	0	0	0	0	0	0
SU-04	S00	SRD	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-05	S00	SAD	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	4	0	4	0	0	0	0	0	0	0
SW-02	800	820	0	0	0	0	0	0	0	2	0	0	1	0	2	0	0
TT-02	600	620	0	0	0	0	0	1	0	2	0	1	1	0	1	0	0
TT-03A	600	620	0	0	0	0	0	1	0	2	0	1	1	0	1	0	0
TT-04B	600	620	0	0	0	0	0	1	0	2	0	1	1	0	1	0	0
** Subtotal **			0	0	0	0	0	27	0	35	0	9	13	0	5	0	0
** 1RS46E **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	0	0	0	4	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	0	0	0	3	0	0
SU-05	S00	SAD	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
SU-05	S00	SRD	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	0	0	0	4	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	19	0	0
** 1RS53E **																	
JU-01	000	000	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
ST-01	600	620	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
** 1V2236 **																	
FS-01	S00	CMD	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
HY-06C	500	520	0	0	0	0	0	1	2	0	0	1	1	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	4	4	0	0	0	0	0	0	0	0
KA-18A	600	600	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
KA-31	600	600	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
RR-04A	800	810	0	0	0	0	0	0	2	0	0	1	1	0	0	0	0
RR-05B	800	810	0	0	0	0	0	0	2	0	0	1	1	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	3	3	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	3	3	0	0	0	0	0	0	0	0
SU-05	S00	CMD	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
SU-05	S00	RMD	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
SU-05	S00	SAD	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
SU-05	S00	SRD	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	4	4	0	0	0	0	0	0	0	0
TB-02	500	520	0	0	0	0	0	1	2	0	0	1	1	0	0	0	0
** Subtotal **			0	0	0	0	2	24	30	0	0	4	4	0	0	0	0
** 1V8R14 **																	
BR-01	700	71D	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
FS-01	S00	CMD	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
GC-01	600	620	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	2	2	2	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	0	4	4	4	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	600	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
PM-02	600	64C	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SP-04	500	520	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	610	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	620	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	2	2	2	0	0	0	0	0	0	0	0	0	0	0
SU-03	S00	CMD	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	2	2	2	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	20	20	20	0	0	0	0	0	0	0	0	0	0	0
** 218A36 **																	
FS-01	S00	CMD	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	4	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	8	0	0	0	0	0	0	0	8	0	0	0	0	0	0
KA-31	600	600	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	3	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	3	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	S00	CMD	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	S00	RMD	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	S00	SAD	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	S00	SRD	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	4	0	0	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** Subtotal **			8	23	0	0	0	0	0	0	8	0	0	0	0	0	0
** <u>246E36</u> **																	
FS-01	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	4	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	3	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	3	0	0	0	0	0	0	0	0	0	0
SU-05	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-05	S00	RMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-05	S00	SAD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-05	S00	SRD	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	4	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	22	0	0	0	0	0	0	0	0	0	0
** <u>253E16</u> **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
JU-01	000	000	0	0	0	0	1	0	0	1	0	0	0	0	0	0	0
ST-01	600	620	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
SU-03	S00	CMD	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	2	0	0	11	0	0	0	0	0	0	0
** <u>2E6B05</u> **																	
FS-01	S00	CMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
JU-09	600	600	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-10	600	600	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	600	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
PM-01	600	64C	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
RT-10	600	64B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RT-11A	600	64B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RT-12B	600	64B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	610	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	620	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
TR-01	400	400	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0

3 Jan 12

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** Subtotal **			0	0	0	19	0	0	0	0	0	0	0	0	0	0	0
** <u>2HML09</u> **																	
NB-03	600	620	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
** <u>2HML27</u> **																	
BR-01	700	71D	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
JU-01	000	000	0	0	0	0	0	0	0	2	0	0	2	0	0	0	0
NB-03	600	620	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
ST-01	600	620	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
SU-05	S00	SAD	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
SU-05	S00	SRD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
TT-02	600	620	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
TT-03A	600	620	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
TT-04B	600	620	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	2	0	0	27	0	0	0	0
** <u>2V2224</u> **																	
FS-01	S00	CMD	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	4	0	0	0	0	0	0	0	0
KA-31	600	600	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	3	0	0	0	0	0	0	0	0
SU-05	S00	SAD	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
SU-05	S00	SRD	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	4	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	19	0	0	0	0	0	0	0	0
** <u>2V8R14</u> **																	
BR-01	700	71D	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
FS-01	S00	CMD	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
GC-01	600	620	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	0	0	4	4	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	600	0	0	3	1	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	610	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
ST-01	600	620	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
SU-03	S00	CMD	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	21	19	0	0	0	0	0	0	0	0	0	0	0

**** 318A36 ****

FA-02A	500	520	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
FA-03B	500	520	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
FS-01	S00	CMD	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
KA-31	600	600	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	3	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	3	0	0	0	0	0	0
SU-05	S00	CMD	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-05	S00	RMD	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-05	S00	SAD	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-05	S00	SRD	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	28	0	0	0	0	0	0

**** 318C24 ****

FA-02A	500	520	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
FA-03B	500	520	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
FS-01	S00	CMD	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	3	0	0	0	0	0	0
SU-05	S00	SAD	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-05	S00	SRD	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	21	0	0	0	0	0	0

**** 346E24 ****

FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
SU-05	S00	SAD	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
SU-05	S00	SRD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	19	0	0	0	0
** <u>353E16</u> **																	
FS-01	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-03	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	10	0	0	0	0	0	0	0	0	0	0
** <u>3E6B05</u> **																	
FS-01	S00	CMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
JU-09	600	600	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-10	600	600	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
PM-01	600	64C	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	610	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	620	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
TR-01	400	400	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	16	0	0	0	0	0	0	0	0	0	0	0
** <u>3HML27</u> **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
NB-03	600	620	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
SU-05	S00	SAD	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
SU-05	S00	SRD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	20	0	0	0	0
** <u>3V2212</u> **																	
FS-01	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
HY-06C	500	520	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
JU-01	S00	SO	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
KA-31	600	600	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
RR-04A	800	810	0	0	0	0	1	1	0	0	0	0	0	0	1	0	0
RR-05B	800	810	0	0	0	0	1	1	0	0	0	0	0	0	1	0	0
SU-01	S00	RMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-03	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
TB-02	500	520	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0
** Subtotal **			0	0	0	0	15	2	0	0	0	0	0	0	4	0	0
** <u>3V8R14</u> **																	
FS-01	S00	CMD	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
SU-03	S00	CMD	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	8	10	0	0	0	0	0	0	0	0	0	0	0
** <u>446E24</u> **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	4	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	3	0	0	0	0	0
SU-05	S00	SAD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-05	S00	SRD	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	4	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	19	0	0	0	0	0
** <u>453E16</u> **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-03	S00	CMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	10	0	0	0	0	0
** <u>4HML27</u> **																	

3 Jan 12

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
FS-01	S00	CMD	0	0	0	0	0	0	0	1	0	1	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	4	0	4	0	0	0	0	0
NB-03	600	620	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	2	0	2	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	3	0	3	0	0	0	0	0
SU-05	S00	SAD	0	0	0	0	0	0	0	1	0	1	0	0	0	0	0
SU-05	S00	SRD	0	0	0	0	0	0	0	2	0	2	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	2	0	2	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	4	0	4	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	21	0	19	0	0	0	0	0
** <u>553E16</u> **																	
FS-01	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-03	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	10	0	0	0	0	0	0	0	0	0	0
** <u>553EXX</u> **																	
FS-01	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-03	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	10	0	0	0	0	0	0	0	0	0	0
** <u>5HML27</u> **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
SU-05	S00	SAD	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
SU-05	S00	SRD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	19	0	0	0	0
** <u>BEAFFW</u> **																	

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
EA-01	ZZC	EAF	1	1	1	2	0	0	0	0	1	0	0	0	0	0	0
EA-02	ZZC	EAF	1	1	1	2	0	0	0	0	1	0	0	0	0	0	0
SU-03	ZZC	EAF	1	1	1	2	0	0	0	0	1	0	0	0	0	0	0
** Subtotal **			3	3	3	6	0	0	0	0	3	0	0	0	0	0	0
** BEAFRW **																	
EA-01	ZZC	EAF	0	0	0	0	1	0	1	0	0	1	1	0	0	0	0
EA-02	ZZC	EAF	0	0	0	0	1	0	1	0	0	1	1	0	0	0	0
SU-03	ZZC	EAF	0	0	0	0	1	0	1	0	0	1	1	0	0	0	0
** Subtotal **			0	0	0	0	3	0	3	0	0	3	3	0	0	0	0
** CCSPFW **																	
AM-01	000	05C	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
BR-04A	700	71D	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
BR-05B	700	71D	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CA-01	AIS	AIS	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CA-01	600	670	2	2	0	2	0	0	0	0	0	0	0	0	0	0	0
CA-04	600	670	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CL-01	600	670	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CL-02	600	670	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CL-04	600	610	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CL-04	600	670	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CL-06	600	670	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CL-07	600	670	4	4	3	4	0	0	0	0	3	0	0	3	0	0	0
CL-09	600	670	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CL-10	600	60A	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CL-10	600	670	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CR-04	600	690	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CS-02A	500	510	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CS-03BM	500	510	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CU-01	900	900	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CU-01	800	800	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CU-01	700	700	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CU-01	700	730	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CU-01	600	600	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CU-01	500	500	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CU-01	400	400	1	1	1	1	0	0	0	0	0	0	0	0	0	0	0
CU-01	000	010	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CU-01	000	020	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CY-01	600	610	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
DP-03	AIS	AIS	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
DP-04	AIS	AIS	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
DP-18A	AIS	AIS	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
FC-05	700	730	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
FS-01	S00	CMD	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
FS-01	900	900	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
FS-01	700	700	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
FS-01	600	600	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
FS-01	500	500	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
FS-01	400	400	1	1	1	1	0	0	0	0	0	0	0	0	1	0	0
GM-02A	700	71B	2	2	2	2	0	0	0	0	2	0	0	1	0	0	0
GM-03B	700	71B	2	2	2	2	0	0	0	0	2	0	0	1	0	0	0
HC-01	500	520	1	1	1	1	0	0	0	0	1	0	0	1	1	0	0
HC-02	500	520	1	1	1	1	0	0	0	0	1	0	0	1	1	0	0
HT-01B	600	69A	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HT-02A	600	69A	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HT-03	600	69A	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HY-04A	500	520	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
HY-05B	500	520	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
JU-01	S00	SO	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
JU-01	700	700	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
JU-01	600	600	13	13	13	13	0	0	0	0	13	0	0	14	0	0	0
JU-01	000	000	12	12	12	12	0	0	0	0	12	0	0	12	0	0	0
KA-01A	600	690	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-02B	600	690	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-03A	600	610	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-04B	600	610	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-05A	600	630	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-06B	600	630	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-07A	600	640	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-08B	600	640	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-18A	600	600	7	7	7	7	0	0	0	0	9	0	0	3	0	0	0
KA-19A	600	630	2	2	2	2	0	0	0	0	2	0	0	1	0	0	0
KA-20B	600	630	2	2	2	2	0	0	0	0	2	0	0	1	0	0	0
KA-31	600	600	3	3	3	3	0	0	0	0	3	0	0	3	0	0	0
LA-01	900	940	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
LA-01	600	620	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
MC-01	900	900	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
MC-01	700	700	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
MC-01	600	670	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
MC-01	000	020	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
MM-01	500	510	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
MM-02	500	510	1	1	1	1	0	0	0	0	1	0	0	1	1	0	0
MM-03	500	510	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
MM-04	500	510	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
NT-06	500	530	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
NT-07	500	530	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
NT-08	500	530	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
NV-01	600	610	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
RR-02	800	810	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
RR-03	800	810	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SE-01	800	810	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SE-05	800	810	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SE-06C	800	810	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SH-03	600	64C	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SH-04	600	64C	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SM-04B	500	510	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SM-05A	500	510	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SM-06B	500	510	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SM-07A	500	510	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
ST-01	600	610	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
ST-01	600	620	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
ST-01	600	62B	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
ST-01	600	64C	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
ST-01	600	64D	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	690	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
ST-01	500	520	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
SU-01	S00	RMD	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-01	600	600	4	4	4	4	0	0	0	0	4	0	0	4	0	0	0
SU-01	000	05C	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-01	000	05D	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-02	S00	CMD	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-03	AIS	AIS	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-03	900	900	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-03	900	990	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-03	700	700	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-05	900	990	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-08	000	05A	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-12	S00	CMD	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-12	S00	RMD	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-12	700	71D	4	4	4	4	0	0	0	0	4	0	0	4	0	0	0
SU-12	000	05A	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TB-01	500	520	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TL-01	600	670	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TL-01	000	040	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TR-01	900	900	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TR-01	500	500	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TR-01	000	05D	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TW-05A	500	510	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TW-06B	500	510	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
VD-07A	600	620	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
VD-08B	600	620	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WC-02	000	030	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
WC-02	000	040	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
WC-08	900	910	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WC-08	900	930	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WC-08	900	940	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WC-12A	900	990	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WC-13BM	900	990	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WL-04A	500	510	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WL-05A	500	510	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WR-01	600	690	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
** Subtotal **			173	174	170	173	0	0	0	0	170	0	0	161	4	0	0
** <u>CCSPRW</u> **																	
AM-01	000	05C	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CA-01	AIS	AIS	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
CA-04	600	670	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CA-07A	600	670	0	0	0	0	0	0	1	0	0	1	1	0	0	0	0
CA-08B	600	670	0	0	0	0	0	0	1	0	0	1	1	0	0	0	0
CA-09	600	670	0	0	0	0	0	0	1	0	0	1	1	0	0	0	0
CL-01	600	670	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
CL-02	600	670	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CL-04	600	610	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
CL-04	600	670	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
CL-06	600	670	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CL-07	600	670	0	0	0	0	3	3	4	3	0	4	4	0	3	0	0
CL-09	600	670	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CL-10	600	60A	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CL-10	600	670	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CR-04	600	690	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
CS-02A	500	510	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CS-03BM	500	510	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	900	900	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
CU-01	800	800	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	700	700	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	700	730	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	600	600	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
CU-01	500	500	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	400	400	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	000	010	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
CU-01	000	020	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	000	040	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CY-01	600	610	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
DP-03	AIS	AIS	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
DP-04	AIS	AIS	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
DP-18A	AIS	AIS	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
FC-05	700	730	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
FS-01	S00	CMD	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
FS-01	900	900	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
FS-01	700	700	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
FS-01	600	600	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
FS-01	500	500	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
FS-01	400	400	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
GM-02A	700	71B	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
GM-03B	700	71B	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
HC-01	500	520	0	0	0	0	1	1	1	1	0	1	1	0	0	0	0
HC-02	500	520	0	0	0	0	1	1	1	1	0	1	1	0	0	0	0
HY-04A	500	520	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
HY-05B	500	520	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
JU-01	800	80	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
JU-01	700	700	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
JU-01	600	600	0	0	0	0	12	12	12	12	0	12	12	0	10	0	0
JU-01	000	000	0	0	0	0	12	12	12	12	0	12	12	0	13	0	0
KA-18A	600	600	0	0	0	0	4	3	4	4	0	4	4	0	3	0	0
KA-31	600	600	0	0	0	0	3	3	3	3	0	3	3	0	3	0	0
LA-01	900	940	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
LA-01	600	620	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
MC-01	900	900	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
MC-01	700	700	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
MC-01	600	670	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
MC-01	000	020	0	0	0	0	2	1	2	2	0	2	2	0	2	0	0
MM-01	500	510	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
MM-02	500	510	0	0	0	0	1	1	1	1	0	1	1	0	0	0	0
MM-03	500	510	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
MM-04	500	510	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
NT-06	500	530	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
NT-07	500	530	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
NT-08	500	530	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
NV-01	600	610	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
PP-01	400	410	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
PP-03A	400	440	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
PP-04BM	400	440	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SE-01	800	810	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SE-02B	800	810	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SE-03C	800	810	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SE-04B	800	810	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SH-06	600	640	0	0	0	0	2	2	2	2	0	2	2	0	1	0	0
SM-04B	500	510	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SM-05A	500	510	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SM-06B	500	510	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SM-07A	500	510	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
ST-01	600	610	0	0	0	0	3	3	3	3	0	3	3	0	3	0	0
ST-01	600	620	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
ST-01	600	62B	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
ST-01	600	640	0	0	0	0	1	1	1	1	0	1	1	0	2	0	0
ST-01	600	690	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
ST-01	500	520	0	0	0	0	0	0	0	0	0	0	0	0	5	0	0
SU-01	S00	RMD	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-01	600	600	0	0	0	0	4	4	4	4	0	4	4	0	4	0	0
SU-01	600	640	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-01	000	05C	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-01	000	05D	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SU-02	S00	CMD	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-03	AIS	AIS	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SU-03	900	900	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SU-03	900	990	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SU-03	700	700	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SU-03	400	410	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SU-05	900	990	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-08	000	05A	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-12	S00	CMD	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-12	S00	RMD	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-12	700	71D	0	0	0	0	2	0	2	2	0	2	2	0	2	0	0
SU-12	400	440	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SU-12	000	05A	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
TB-01	500	520	0	0	0	0	1	1	0	2	0	1	1	0	1	0	0
TL-01	600	670	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
TL-01	000	040	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
TR-01	900	900	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
TR-01	500	500	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
TR-01	400	440	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
TR-01	000	05D	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
TW-05A	500	510	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
TW-06B	500	510	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
VD-05A	600	620	0	0	0	0	0	1	1	1	0	1	1	0	0	0	0
VD-06B	600	620	0	0	0	0	0	1	1	1	0	1	1	0	0	0	0
WC-02	000	030	0	0	0	0	2	0	2	2	0	2	2	0	2	0	0
WC-02	000	040	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
WC-08	900	910	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
WC-08	900	930	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
WC-08	900	940	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
WC-12A	900	990	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
WC-13BM	900	990	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
WL-04A	500	510	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
WL-05A	500	510	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
WR-01	600	690	0	0	0	0	1	1	1	1	0	1	1	0	0	0	0
** Subtotal **			0	0	0	0	162	147	167	165	0	168	168	0	161	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** F1130T **																	
JU-01	000	000	0	0	0	0	0	0	0	0	0	0	0	1	1	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	1	1	0	0
** F15316 **																	
FS-01	S00	CMD	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
JU-01	000	000	0	0	0	0	1	1	0	1	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	1	7	0	7	0	0	0	0	0	0	0
** F18A36 **																	
FS-01	S00	CMD	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-01	S00	RMD	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			11	0	0	0	0	0	0	0	1	0	0	0	0	0	0
** F18C24 **																	
FS-01	S00	CMD	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-01	S00	RMD	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			11	0	0	0	0	0	0	0	1	0	0	0	0	0	0
** F18R14 **																	
FS-01	S00	CMD	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	6	7	7	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** F1E605 **																	
FS-01	S00	CMD	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	5	0	6	0	0	0	0	0	0	0	0	0	0	0
** F1H127 **																	
FS-01	S00	CMD	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	10	0	10	0	0	0	0	0	0	0
** F1V224 **																	
FS-01	S00	CMD	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	10	10	0	0	0	0	0	0	0	0
** F25316 **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
JU-01	000	000	0	0	0	0	1	0	0	1	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	1	0	0	7	0	0	0	0	0	0	0
** F28A36 **																	
FS-01	S00	CMD	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-01	S00	RMD	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
SU-12	S00	RMD	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			1	10	0	0	0	0	0	0	1	0	0	0	0	0	0
** F28R14 **																	
FS-01	S00	CMD	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	7	7	0	0	0	0	0	0	0	0	0	0	0
** F2E605 **																	
FS-01	S00	CMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	6	0	0	0	0	0	0	0	0	0	0	0
** F2H127 **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	10	0	0	0	0
** F2V224 **																	
FS-01	S00	CMD	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	10	0	0	0	0	0	0	0	0
** F30J12 **																	
FS-01	S00	CMD	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
JU-01	S00	SO	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
JU-01	000	000	1	0	0	1	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
SU-01	S00	RMD	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SU-02	S00	CMD	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SU-12	S00	CMD	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SU-12	S00	RMD	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
** Subtotal **			7	0	0	7	0	0	0	0	0	6	0	0	0	0	0
** F34624 **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
** Subtotal **			0	0	10	0	0	0	0								
** F35316 **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
** Subtotal **			0	6	0	0	0	0	0								
** F38A36 **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
** Subtotal **			0	10	0	0	0	0	0	0							
** F38C24 **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
** Subtotal **			0	10	0	0	0	0	0	0							
** F3E605 **																	

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
FS-01	S00	CMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	6	0	0	0	0	0	0	0	0	0	0	0
** F3H127 **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	10	0	0	0	0	0
** F3V224 **																	
FS-01	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	10	0	0	0	0	0	0	0	0	0	0
** F44624 **																	
FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	10	0	0	0	0	0
** F45316 **																	
FS-01	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
JU-01	S00	SO	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-01	S00	RMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-02	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	S00	RMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	6	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS	
** F46FSP **																		
FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0	
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0	
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0	
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0	
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	10	0	0	
** F4H127 **																		
FS-01	S00	CMD	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	
JU-01	S00	SO	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0	
SU-01	S00	RMD	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0	
SU-02	S00	CMD	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0	
SU-12	S00	CMD	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	
SU-12	S00	RMD	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0	
** Subtotal **			0	0	0	0	0	0	0	10	0	0	0	0	0	0	0	0
** F54636 **																		
FS-01	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
JU-01	S00	SO	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
SU-01	S00	RMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
SU-02	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
SU-12	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
SU-12	S00	RMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			0	0	0	0	6	0	0	0	0	0	0	0	0	0	0	0
** F55316 **																		
FS-01	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
JU-01	S00	SO	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
SU-01	S00	RMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
SU-02	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
SU-12	S00	CMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
SU-12	S00	RMD	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	
** Subtotal **			0	0	0	0	6	0	0	0	0	0	0	0	0	0	0	0
** F5H127 **																		
FS-01	S00	CMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	
JU-01	S00	SO	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0	
SU-01	S00	RMD	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0	
SU-02	S00	CMD	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0	
SU-12	S00	CMD	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	
SU-12	S00	RMD	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0	

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** Subtotal **			0	0	0	0	0	0	0	0	0	0	10	0	0	0	0
** <u>HMXXXX</u> **																	
CA-04	600	670	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CL-01	600	670	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CL-02	600	670	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CL-04	600	610	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CL-04	600	670	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CL-06	600	670	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CL-07	600	670	0	0	0	0	0	0	0	0	0	0	0	0	0	3	0
CL-10	600	60A	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CR-04	600	690	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CU-01	600	600	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
HY-04A	500	520	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
HY-05B	500	520	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
HY-06C	500	520	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
JU-01	600	600	0	0	0	0	0	0	0	0	0	0	0	0	0	5	0
KA-18A	600	600	0	0	0	0	0	0	0	0	0	0	0	0	0	2	0
LA-01	600	620	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
NB-03	600	620	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
RR-04A	800	810	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
RR-05B	800	810	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
SH-06	600	640	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
ST-01	600	610	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
ST-01	600	620	0	0	0	0	0	0	0	0	0	0	0	0	0	2	0
ST-01	600	690	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
SU-03	AIS	AIS	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
SU-05	900	990	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
TB-02	500	520	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
TL-01	600	670	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
VD-07A	600	620	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
VD-08B	600	620	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
WC-12A	900	990	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
WC-13BM	900	990	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	39	0
** <u>IOSP11</u> **																	
JU-01	600	600	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-07A	600	640	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-08B	600	640	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-18A	600	600	6	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-19A	600	630	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-20B	600	630	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	600	11	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			21	0	0	0	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** IOSP12 **																	
EB-06	600	64B	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
EB-07	600	64B	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
EB-09	600	64B	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-07A	600	640	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-08B	600	640	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-18A	600	600	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	600	0	11	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	16	0	0	0	0	0	0	0	0	0	0	0	0	0
** IOSP13 **																	
JU-01	600	600	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	600	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	1	0	0	0	0	0	0	0	0	0	0	0	0
** IOSP14 **																	
CL-09	600	670	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
DP-18A	AIS	AIS	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
EB-06	600	64B	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
EB-07	600	64B	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
EB-08	600	64B	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
EB-09	600	64B	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
EB-14A	600	64B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
EB-15B	600	64B	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	600	600	0	0	0	6	0	0	0	0	0	0	0	0	0	0	0
KA-18A	600	600	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
KA-19A	600	630	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
KA-20B	600	630	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	600	0	0	0	4	0	0	0	0	0	0	0	0	0	0	0
SU-01	600	600	0	0	0	4	0	0	0	0	0	0	0	0	0	0	0
SU-01	600	64B	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-03	600	600	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
SU-03	600	670	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	600	670	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	37	0										
** IOSP16 **																	
DP-18A	AIS	AIS	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	1	0									
** IOSP31 **																	
JU-01	600	600	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
KA-01A	600	690	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
KA-02B	600	690	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-05A	600	630	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-06B	600	630	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-07A	600	640	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-08B	600	640	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-18A	600	600	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
KA-19A	600	630	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
KA-20B	600	630	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
KA-31	600	600	0	0	0	0	0	0	0	0	9	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	16	0	0	0	0	0	0
** <u>IOSP36</u> **																	
DP-18A	AIS	AIS	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
** <u>IOSP41</u> **																	
DP-18A	AIS	AIS	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
KA-31	600	600	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
** <u>IOSP49</u> **																	
KA-18A	600	600	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
** <u>MACSXX</u> **																	
AT-11	ATC	ATC	0	1	1	1	1	0	0	1	1	1	2	1	0	0	0
AT-12	ATC	ATC	0	1	1	1	1	0	0	1	1	1	2	1	0	0	0
CR-03	ATC	ATC	0	2	2	2	2	0	0	2	2	2	4	2	0	0	0
JU-01	ATC	ATC	0	1	1	2	1	0	0	1	1	1	2	1	0	0	0
SU-03	ATC	ATC	0	1	1	2	1	0	0	1	1	1	2	0	0	0	0
WJ-06	ATC	ATC	0	1	2	2	1	0	0	1	1	1	1	1	1	0	0
** Subtotal **			0	7	8	10	7	0	0	7	7	7	13	6	1	0	0
** <u>MPSXXX</u> **																	
EA-01	MPS	MP1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
EA-01	MPS	MP2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
EA-01	MPS	MP3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
EA-02	MPS	MP1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
EA-02	MPS	MP2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
EA-02	MPS	MP3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
FS-01	MPS	BI	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
JU-01	MPS	BI	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
LA-01	MPS	BI	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
LA-01	MPS	MP1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
LA-01	MPS	MP2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
LA-01	MPS	MP3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
NB-03	MPS	BI	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
NB-03	MPS	MP1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
NB-03	MPS	MP2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
NB-03	MPS	MP3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
SU-03	MPS	MP1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
SU-03	MPS	MP2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
SU-03	MPS	MP3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
SU-12	MPS	BI	0	0	0	0	0	0	0	0	0	0	0	0	0	0	8
SU-12	MPS	MP1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	12
SU-12	MPS	MP2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	12
SU-12	MPS	MP3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	12
TW-05A	MPS	BI	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
TW-05A	MPS	MP1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
TW-05A	MPS	MP2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
TW-05A	MPS	MP3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
TW-06B	MPS	BI	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
TW-06B	MPS	MP1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
TW-06B	MPS	MP2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
TW-06B	MPS	MP3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	86
** <u>PALMXX</u> **																	
CU-01	700	700	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
EA-01	ZZC	EAF	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
EA-02	ZZC	EAF	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	700	700	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			4	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** <u>SCIFXX</u> **																	
AB-02	000	S3	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
AB-03	000	S3	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
JU-31	000	S3	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
JU-32	000	S3	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
** Subtotal **			4	4	0	0	0	0	0	0	4	0	0	0	0	0	0
** <u>T30F14</u> **																	
EA-01	ZZC	EAF	0	0	0	0	0	0	0	0	0	0	0	1	1	0	0
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	1	1	0	0
** <u>T53E29</u> **																	
HY-04A	500	520	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
HY-05B	500	520	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
JU-01	600	600	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
LA-01	600	620	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
ST-01	600	610	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
ST-01	600	620	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	0	7	0	0	0	0	0	0	0
** <u>TFRS11</u> **																	
AM-01	000	05C	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
CU-01	900	900	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
CU-01	800	800	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
CU-01	600	600	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
CU-01	500	500	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
CU-01	400	400	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
CU-01	000	010	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
CU-01	000	020	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
CY-01	600	610	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
EA-02	ZZC	EAF	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FA-02A	500	520	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FA-03B	500	520	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
GM-02A	700	71B	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
GM-03B	700	71B	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HC-01	500	520	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HC-02	500	520	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HT-01B	600	69A	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HT-02A	600	69A	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HT-03	600	69A	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	700	700	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	600	600	7	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	10	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-01A	600	690	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-02B	600	690	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-03A	600	610	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-04B	600	610	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-05A	600	630	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-06B	600	630	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-07A	600	640	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-08B	600	640	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-18A	600	600	6	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-19A	600	630	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-20B	600	630	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	600	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
LA-01	600	620	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
MC-01	000	020	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
MM-01	500	510	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
MM-02	500	510	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
MM-03	500	510	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
MM-04	500	510	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
NT-06	500	530	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
NT-07	500	530	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
NT-08	500	530	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RR-02	800	810	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SE-01	800	810	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SM-04B	500	510	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SM-05A	500	510	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SM-06B	500	510	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SM-07A	500	510	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	610	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	620	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	62B	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	64C	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	500	520	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-01	000	05C	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	900	990	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	000	05A	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SW-02	800	820	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
TB-01	500	520	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
TR-01	900	900	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
TR-01	000	05D	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
VD-07A	600	620	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
VD-08B	600	620	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
WC-02	000	030	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
WC-02	000	040	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
WC-08	900	910	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
WC-08	900	930	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
WC-08	900	940	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
WL-04A	500	510	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
WL-05A	500	510	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			79	0													
** TH1M39 **																	
HY-04A	500	520	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
HY-05B	500	520	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
JU-01	600	600	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
NB-03	600	620	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
ST-01	600	610	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
ST-01	600	620	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
SW-02	800	820	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
VD-05A	600	620	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
VD-06B	600	620	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0

USMC MF TBA by Contingency Support Package

CONFIG	DIV	BR	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** Subtotal **			0	0	0	0	0	0	0	0	0	0	9	0	0	0	0
** TV2226 **																	
HY-06C	500	520	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
KA-18A	600	600	0	0	0	0	0	0	4	0	0	0	0	0	0	0	0
KA-31	600	600	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
RR-04A	800	810	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
RR-05B	800	810	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
TB-02	500	520	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	0	0	9	0	0	0	0	0	0	0	0
** TV8B14 **																	
CL-01	600	670	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
EA-01	ZZC	EAF	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
EA-02	ZZC	EAF	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
HY-04A	500	520	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
HY-05B	500	520	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	600	600	0	0	0	4	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	000	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
KA-05A	600	630	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-06B	600	630	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-07A	600	640	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-08B	600	640	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-18A	600	600	0	0	0	5	0	0	0	0	0	0	0	0	0	0	0
KA-19A	600	630	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
KA-20B	600	630	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	600	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
LA-01	600	620	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
MC-01	000	020	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	610	0	0	0	6	0	0	0	0	0	0	0	0	0	0	0
ST-01	600	620	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
ST-01	500	520	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	000	05C	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
VD-07A	600	620	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
VD-08B	600	620	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	35	0	0	0	0	0	0	0	0	0	0	0
** WGISSX **																	
EA-01	ZZC	EAF	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
JU-01	600	600	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
LA-01	600	620	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
** Subtotal **			0	0	0	0	3	0	0	0	0	0	0	0	0	0	0
Total			415	310	245	416	284	239	248	295	311	302	338	193	221	39	86

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
**	<u>000</u>	**															
AB-02	S3	SCIFXX	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
AB-03	S3	SCIFXX	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
AM-01	05C	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
AM-01	05C	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
AM-01	05C	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
AT-08	S2	118A36	2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
AT-09BM	210	118A36	2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
AT-10A	210	118A36	2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
CU-01	040	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	020	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CU-01	020	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	020	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
CU-01	010	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CU-01	010	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
CU-01	010	TFRS11	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	118A12	0	0	0	0	0	0	0	0	0	0	0	6	0	0	0
JU-01	000	118A36	8	8	0	0	0	0	0	0	8	0	0	0	0	0	0
JU-01	000	118C24	6	0	0	0	0	0	0	0	6	0	0	0	0	0	0
JU-01	000	130J12	2	0	0	2	0	0	0	0	0	2	0	0	0	0	0
JU-01	000	130T12	0	0	0	0	0	0	0	0	0	0	0	3	3	0	0
JU-01	000	146E36	0	0	0	0	2	0	0	0	0	2	2	0	0	0	0
JU-01	000	153E16	0	0	0	0	1	1	0	1	0	1	0	0	0	0	0
JU-01	000	1E6B05	0	3	0	3	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	1HML27	0	0	0	0	0	2	0	2	0	2	2	0	0	0	0
JU-01	000	1RS53E	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
JU-01	000	1V8R14	0	4	4	4	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	218A36	8	0	0	0	0	0	0	0	8	0	0	0	0	0	0
JU-01	000	253E16	0	0	0	0	1	0	0	1	0	0	0	0	0	0	0
JU-01	000	2E6B05	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	2HML27	0	0	0	0	0	0	0	2	0	0	2	0	0	0	0
JU-01	000	2V8R14	0	0	4	4	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	3E6B05	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	CCSPFW	12	12	12	12	0	0	0	0	12	0	0	12	0	0	0
JU-01	000	CCSPRW	0	0	0	0	12	12	12	12	0	12	12	0	13	0	0
JU-01	000	F1130T	0	0	0	0	0	0	0	0	0	0	0	1	1	0	0
JU-01	000	F15316	0	0	0	0	1	1	0	1	0	0	0	0	0	0	0
JU-01	000	F18A36	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0
JU-01	000	F18C24	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
JU-01	000	F18R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	F1E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	F25316	0	0	0	0	1	0	0	1	0	0	0	0	0	0	0
JU-01	000	F28A36	1	0	0	0	0	0	0	0	1	0	0	0	0	0	0
JU-01	000	F28R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	F2E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	F30J12	1	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	F3E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	TFRS11	10	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	000	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-31	S3	SCIFXX	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
JU-32	S3	SCIFXX	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
MC-01	020	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
MC-01	020	CCSPRW	0	0	0	0	2	1	2	2	0	2	2	0	2	0	0
MC-01	020	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
MC-01	020	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	05D	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-01	05D	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SU-01	05C	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-01	05C	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-01	05C	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-01	05C	TV8B14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
SU-08	05A	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-08	05A	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-12	05A	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-12	05A	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SU-12	05A	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
TL-01	040	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TL-01	040	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
TR-01	05D	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TR-01	05D	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
TR-01	05D	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
WC-02	040	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
WC-02	040	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
WC-02	040	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
WC-02	030	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
WC-02	030	CCSPRW	0	0	0	0	2	0	2	2	0	2	2	0	2	0	0
WC-02	030	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			86	53	38	57	35	28	29	37	63	36	35	38	35	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** 400 **																	
CU-01	400	CCSPFW	1	1	1	1	0	0	0	0	0	0	0	0	0	0	0
CU-01	400	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	400	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FS-01	400	CCSPFW	1	1	1	1	0	0	0	0	0	0	0	0	1	0	0
FS-01	400	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
PP-01	410	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
PP-03A	440	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
PP-04BM	440	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-03	410	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SU-12	440	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
TR-01	440	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
TR-01	400	118A12	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
TR-01	400	118A36	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0
TR-01	400	118C24	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
TR-01	400	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
TR-01	400	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
TR-01	400	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			5	4	2	5	8	5	8	8	0	8	8	1	9	0	0
** 500 **																	
CS-02A	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CS-02A	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CS-03BM	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CS-03BM	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	500	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CU-01	500	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	500	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FA-02A	520	118A12	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
FA-02A	520	118A36	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0
FA-02A	520	118C24	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FA-02A	520	318A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
FA-02A	520	318C24	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
FA-02A	520	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FA-03B	520	118A12	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
FA-03B	520	118A36	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0
FA-03B	520	118C24	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FA-03B	520	318A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
FA-03B	520	318C24	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
FA-03B	520	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
FS-01	500	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
FS-01	500	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
HC-01	520	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	1	0	0
HC-01	520	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	0	0	0
HC-01	520	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HC-02	520	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	1	0	0
HC-02	520	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	0	0	0
HC-02	520	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HY-04A	520	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
HY-04A	520	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
HY-04A	520	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
HY-04A	520	T53E29	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
HY-04A	520	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
HY-04A	520	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
HY-05B	520	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
HY-05B	520	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
HY-05B	520	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
HY-05B	520	T53E29	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
HY-05B	520	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
HY-05B	520	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
HY-06C	520	1V2236	0	0	0	0	0	1	2	0	0	1	1	0	0	0	0
HY-06C	520	3V2212	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0
HY-06C	520	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
HY-06C	520	TV2226	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
MM-01	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
MM-01	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
MM-01	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
MM-02	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	1	0	0
MM-02	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	0	0	0
MM-02	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
MM-03	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
MM-03	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
MM-03	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
MM-04	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
MM-04	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
MM-04	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
NT-06	530	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
NT-06	530	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
NT-06	530	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
NT-07	530	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
NT-07	530	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
NT-07	530	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
NT-08	530	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
NT-08	530	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
NT-08	530	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SM-04B	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SM-04B	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SM-04B	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SM-05A	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SM-05A	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SM-05A	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SM-06B	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SM-06B	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SM-06B	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SM-07A	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SM-07A	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SM-07A	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SP-04	520	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
ST-01	520	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
ST-01	520	CCSPRW	0	0	0	0	0	0	0	0	0	0	0	0	5	0	0
ST-01	520	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	520	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
TB-01	520	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TB-01	520	CCSPRW	0	0	0	0	1	1	0	2	0	1	1	0	1	0	0
TB-01	520	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
TB-02	520	1V2236	0	0	0	0	0	1	2	0	0	1	1	0	0	0	0
TB-02	520	3V2212	0	0	0	0	1	0	0	0	0	0	0	0	1	0	0
TB-02	520	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
TB-02	520	TV2226	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
TR-01	500	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TR-01	500	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
TW-05A	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TW-05A	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
TW-06B	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TW-06B	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
WL-04A	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WL-04A	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
WL-04A	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
WL-05A	510	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WL-05A	510	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
WL-05A	510	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
** Subtotal **			51	30	28	31	27	27	30	28	31	27	29	29	32	4	0
** <u>600</u> **																	
CA-01	670	CCSPFW	2	2	0	2	0	0	0	0	0	0	0	0	0	0	0
CA-04	670	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CA-04	670	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CA-04	670	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CA-07A	670	CCSPRW	0	0	0	0	0	0	1	0	0	1	1	0	0	0	0
CA-08B	670	CCSPRW	0	0	0	0	0	0	1	0	0	1	1	0	0	0	0
CA-09	670	CCSPRW	0	0	0	0	0	0	1	0	0	1	1	0	0	0	0
CL-01	670	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CL-01	670	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
CL-01	670	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CL-01	670	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
CL-02	670	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CL-02	670	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CL-02	670	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CL-04	670	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CL-04	670	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
CL-04	670	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CL-04	610	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CL-04	610	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
CL-04	610	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CL-06	670	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CL-06	670	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CL-06	670	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CL-07	670	CCSPFW	4	4	3	4	0	0	0	0	3	0	0	3	0	0	0
CL-07	670	CCSPRW	0	0	0	0	3	3	4	3	0	4	4	0	3	0	0
CL-07	670	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	3	0
CL-09	670	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CL-09	670	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CL-09	670	IOSP14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
CL-10	670	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CL-10	670	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CL-10	60A	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CL-10	60A	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CL-10	60A	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CR-04	690	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CR-04	690	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMK	MPS
CR-04	690	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CU-01	600	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CU-01	600	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
CU-01	600	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
CU-01	600	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
CY-01	610	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CY-01	610	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CY-01	610	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
EB-06	64B	IOSP12	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
EB-06	64B	IOSP14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
EB-07	64B	IOSP12	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
EB-07	64B	IOSP14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
EB-08	64B	IOSP14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
EB-09	64B	IOSP12	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
EB-09	64B	IOSP14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
EB-14A	64B	IOSP14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
EB-15B	64B	IOSP14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FS-01	600	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
FS-01	600	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
GC-01	620	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
GC-01	620	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
HT-01B	69A	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HT-01B	69A	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HT-02A	69A	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HT-02A	69A	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HT-03	69A	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
HT-03	69A	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	600	CCSPFW	13	13	13	13	0	0	0	0	13	0	0	14	0	0	0
JU-01	600	CCSPRW	0	0	0	0	12	12	12	12	0	12	12	0	10	0	0
JU-01	600	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	5	0
JU-01	600	IOSP11	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	600	IOSP13	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	600	IOSP14	0	0	0	6	0	0	0	0	0	0	0	0	0	0	0
JU-01	600	IOSP31	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
JU-01	600	T53E29	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
JU-01	600	TFRS11	7	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	600	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
JU-01	600	TV8B14	0	0	0	4	0	0	0	0	0	0	0	0	0	0	0
JU-01	600	WGISSX	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
JU-09	600	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
JU-09	600	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-09	600	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-10	600	1E6B05	0	2	0	2	0	0	0	0	0	0	0	0	0	0	0
JU-10	600	2E6B05	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
JU-10	600	3E6B05	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
KA-01A	690	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-01A	690	IOSP31	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-01A	690	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-02B	690	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-02B	690	IOSP31	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-02B	690	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-03A	610	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-03A	610	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-04B	610	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-04B	610	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-05A	630	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-05A	630	IOSP31	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-05A	630	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-05A	630	TV8B14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-06B	630	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-06B	630	IOSP31	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-06B	630	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-06B	630	TV8B14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-07A	640	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-07A	640	IOSP11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-07A	640	IOSP12	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-07A	640	IOSP31	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-07A	640	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-07A	640	TV8B14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-08B	640	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-08B	640	IOSP11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-08B	640	IOSP12	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-08B	640	IOSP31	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-08B	640	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-08B	640	TV8B14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-18A	600	1HML27	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
KA-18A	600	1V2236	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
KA-18A	600	CCSPFW	7	7	7	7	0	0	0	0	9	0	0	3	0	0	0
KA-18A	600	CCSPRW	0	0	0	0	4	3	4	4	0	4	4	0	3	0	0
KA-18A	600	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	2	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
KA-18A	600	IOSP11	6	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-18A	600	IOSP12	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-18A	600	IOSP14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
KA-18A	600	IOSP31	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
KA-18A	600	IOSP49	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
KA-18A	600	TFRS11	6	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-18A	600	TV2226	0	0	0	0	0	0	4	0	0	0	0	0	0	0	0
KA-18A	600	TV8B14	0	0	0	5	0	0	0	0	0	0	0	0	0	0	0
KA-19A	630	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	1	0	0	0
KA-19A	630	IOSP11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-19A	630	IOSP14	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
KA-19A	630	IOSP31	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
KA-19A	630	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-19A	630	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
KA-20B	630	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	1	0	0	0
KA-20B	630	IOSP11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-20B	630	IOSP14	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
KA-20B	630	IOSP31	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
KA-20B	630	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-20B	630	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	118A12	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
KA-31	600	118A36	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	1E6B05	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	1HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
KA-31	600	1V2236	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	1V8R14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	218A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	2E6B05	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	2V2224	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	2V8R14	0	0	3	1	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	318A36	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
KA-31	600	3V2212	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
KA-31	600	CCSPFW	3	3	3	3	0	0	0	0	3	0	0	3	0	0	0
KA-31	600	CCSPRW	0	0	0	0	3	3	3	3	0	3	3	0	3	0	0
KA-31	600	IOSP11	11	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	IOSP12	0	11	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	IOSP13	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	IOSP14	0	0	0	4	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	IOSP31	0	0	0	0	0	0	0	0	9	0	0	0	0	0	0
KA-31	600	IOSP41	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
KA-31	600	TFRS11	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
KA-31	600	TV2226	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
KA-31	600	TV8B14	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
LA-01	620	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
LA-01	620	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
LA-01	620	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
LA-01	620	T53E29	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
LA-01	620	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
LA-01	620	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
LA-01	620	WGISSX	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
MC-01	670	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
MC-01	670	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
NB-03	620	1HML09	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
NB-03	620	1HML27	0	0	0	0	0	1	0	2	0	2	0	0	0	0	0
NB-03	620	2HML09	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
NB-03	620	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
NB-03	620	3HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
NB-03	620	4HML27	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
NB-03	620	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
NB-03	620	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
NV-01	610	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
NV-01	610	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
PM-01	64C	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
PM-01	64C	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
PM-01	64C	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
PM-02	64C	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
RT-10	64B	1E6B05	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RT-10	64B	2E6B05	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RT-11A	64B	1E6B05	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RT-11A	64B	2E6B05	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RT-12B	64B	1E6B05	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RT-12B	64B	2E6B05	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SH-03	64C	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SH-04	64C	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SH-06	64C	130J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SH-06	64C	130T12	0	0	0	0	0	0	0	0	0	0	0	1	1	0	0
SH-06	640	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	1	0	0
SH-06	640	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
ST-01	690	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
ST-01	690	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
ST-01	690	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
ST-01	64D	118A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	64D	CCSPFW	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	64C	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
ST-01	64C	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	640	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	2	0	0
ST-01	62B	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
ST-01	62B	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
ST-01	62B	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	620	118A36	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
ST-01	620	118C24	1	0	0	0	0	0	0	0	1	0	0	1	0	0	0
ST-01	620	130T12	0	0	0	0	0	0	0	0	0	0	0	1	1	0	0
ST-01	620	146E36	0	0	0	0	1	0	0	0	0	1	1	0	0	0	0
ST-01	620	153E16	0	0	0	0	1	1	0	2	0	1	0	0	0	0	0
ST-01	620	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
ST-01	620	1HML27	0	0	0	0	0	1	0	2	0	1	1	0	0	0	0
ST-01	620	1RS53E	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
ST-01	620	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
ST-01	620	253E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
ST-01	620	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
ST-01	620	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
ST-01	620	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
ST-01	620	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
ST-01	620	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
ST-01	620	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
ST-01	620	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	2	0
ST-01	620	T53E29	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
ST-01	620	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	620	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
ST-01	620	TV8B14	0	0	0	3	0	0	0	0	0	0	0	0	0	0	0
ST-01	610	118A36	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
ST-01	610	118C24	1	0	0	0	0	0	0	0	1	0	0	1	0	0	0
ST-01	610	130T12	0	0	0	0	0	0	0	0	0	0	0	3	3	0	0
ST-01	610	1E6B05	0	2	0	2	0	0	0	0	0	0	0	0	0	0	0
ST-01	610	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
ST-01	610	2E6B05	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
ST-01	610	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
ST-01	610	3E6B05	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
ST-01	610	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
ST-01	610	CCSPRW	0	0	0	0	3	3	3	3	0	3	3	0	3	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
ST-01	610	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
ST-01	610	T53E29	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
ST-01	610	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
ST-01	610	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
ST-01	610	TV8B14	0	0	0	6	0	0	0	0	0	0	0	0	0	0	0
SU-01	64B	IOSP14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	640	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-01	600	CCSPFW	4	4	4	4	0	0	0	0	4	0	0	4	0	0	0
SU-01	600	CCSPRW	0	0	0	0	4	4	4	4	0	4	4	0	4	0	0
SU-01	600	IOSP14	0	0	0	4	0	0	0	0	0	0	0	0	0	0	0
SU-03	670	IOSP14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-03	630	118A36	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-03	630	118C24	1	0	0	0	0	0	0	0	1	0	0	1	0	0	0
SU-03	600	IOSP14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
SU-12	670	IOSP14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
TL-01	670	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TL-01	670	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
TL-01	670	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
TT-02	620	1HML27	0	0	0	0	0	1	0	2	0	1	1	0	1	0	0
TT-02	620	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
TT-03A	620	1HML27	0	0	0	0	0	1	0	2	0	1	1	0	1	0	0
TT-03A	620	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
TT-04B	620	1HML27	0	0	0	0	0	1	0	2	0	1	1	0	1	0	0
TT-04B	620	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
VD-05A	620	CCSPRW	0	0	0	0	0	1	1	1	0	1	1	0	0	0	0
VD-05A	620	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
VD-06B	620	CCSPRW	0	0	0	0	0	1	1	1	0	1	1	0	0	0	0
VD-06B	620	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
VD-07A	620	130T12	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
VD-07A	620	153E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
VD-07A	620	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
VD-07A	620	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
VD-07A	620	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
VD-07A	620	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
VD-08B	620	130T12	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
VD-08B	620	153E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
VD-08B	620	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
VD-08B	620	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
VD-08B	620	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
VD-08B	620	TV8B14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
WR-01	690	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WR-01	690	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	0	0	0
** Subtotal **			122	101	76	164	69	66	70	80	93	74	87	69	69	29	0
** 700 **																	
BR-01	71D	118A36	2	2	0	0	0	0	0	0	2	0	0	0	0	0	0
BR-01	71D	118C24	1	0	0	0	0	0	0	0	1	0	0	1	0	0	0
BR-01	71D	1HML27	0	0	0	0	0	1	0	2	0	1	1	0	0	0	0
BR-01	71D	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
BR-01	71D	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
BR-01	71D	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
BR-04A	71D	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
BR-05B	71D	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CU-01	730	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CU-01	730	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	700	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CU-01	700	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	700	PALMXX	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FC-05	730	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
FC-05	730	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
FS-01	700	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
FS-01	700	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
GM-02A	71B	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	1	0	0	0
GM-02A	71B	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
GM-02A	71B	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
GM-03B	71B	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	1	0	0	0
GM-03B	71B	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
GM-03B	71B	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	700	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
JU-01	700	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
JU-01	700	PALMXX	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	700	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
MC-01	700	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
MC-01	700	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-03	700	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-03	700	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SU-12	71D	CCSPFW	4	4	4	4	0	0	0	0	4	0	0	4	0	0	0
SU-12	71D	CCSPRW	0	0	0	0	2	0	2	2	0	2	2	0	2	0	0
** Subtotal **			26	21	20	20	12	10	12	14	21	13	14	17	12	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
**	<u>800</u>	**															
CU-01	800	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CU-01	800	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
CU-01	800	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RR-02	810	130J12	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
RR-02	810	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
RR-02	810	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
RR-03	810	130J12	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
RR-03	810	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
RR-04A	810	1V2236	0	0	0	0	0	0	2	0	0	1	1	0	0	0	0
RR-04A	810	3V2212	0	0	0	0	1	1	0	0	0	0	0	0	1	0	0
RR-04A	810	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
RR-04A	810	TV2226	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
RR-05B	810	1V2236	0	0	0	0	0	0	2	0	0	1	1	0	0	0	0
RR-05B	810	3V2212	0	0	0	0	1	1	0	0	0	0	0	0	1	0	0
RR-05B	810	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
RR-05B	810	TV2226	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
SE-01	810	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SE-01	810	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SE-01	810	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SE-02B	810	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SE-03C	810	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SE-04B	810	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SE-05	810	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SE-06C	810	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SW-02	820	118A36	1	1	0	0	0	0	0	0	1	0	0	1	0	0	0
SW-02	820	118C24	1	1	0	0	0	0	0	0	1	0	0	0	0	0	0
SW-02	820	1HML27	0	0	0	0	0	0	0	2	0	0	1	0	2	0	0
SW-02	820	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SW-02	820	TH1M39	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
** Subtotal **			12	8	6	6	7	6	11	7	8	9	9	7	9	2	0
**	<u>900</u>	**															
CU-01	900	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
CU-01	900	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
CU-01	900	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FS-01	900	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
FS-01	900	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
LA-01	940	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
LA-01	940	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
MC-01	900	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
MC-01	900	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-03	990	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-03	990	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SU-03	900	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-03	900	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SU-05	990	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-05	990	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-05	990	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
SU-05	990	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
TR-01	900	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
TR-01	900	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
TR-01	900	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
WC-08	940	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WC-08	940	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
WC-08	940	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
WC-08	930	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WC-08	930	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
WC-08	930	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
WC-08	910	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WC-08	910	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
WC-08	910	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
WC-12A	990	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WC-12A	990	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
WC-12A	990	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
WC-13BM	990	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
WC-13BM	990	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
WC-13BM	990	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
** Subtotal **			19	13	13	13	13	10	13	3	0						
** AIS **																	
CA-01	AIS	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
CA-01	AIS	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
DP-03	AIS	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
DP-03	AIS	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
DP-04	AIS	CCSPFW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
DP-04	AIS	CCSPRW	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
DP-18A	AIS	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
DP-18A	AIS	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
DP-18A	AIS	IOSP14	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
DP-18A	AIS	IOSP16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
DP-18A	AIS	IOSP36	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
DP-18A	AIS	IOSP41	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
SU-03	AIS	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-03	AIS	CCSPRW	0	0	0	0	1	0	1	1	0	1	1	0	1	0	0
SU-03	AIS	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
** Subtotal **			5	5	5	6	6	4	5	5	5	6	5	6	5	1	0
** ATC **																	
AT-11	ATC	MACSXX	0	1	1	1	1	0	0	1	1	1	2	1	0	0	0
AT-12	ATC	MACSXX	0	1	1	1	1	0	0	1	1	1	2	1	0	0	0
CR-03	ATC	MACSXX	0	2	2	2	2	0	0	2	2	2	4	2	0	0	0
JU-01	ATC	MACSXX	0	1	1	2	1	0	0	1	1	1	2	1	0	0	0
SU-03	ATC	MACSXX	0	1	1	2	1	0	0	1	1	1	2	0	0	0	0
WJ-06	ATC	MACSXX	0	1	2	2	1	0	0	1	1	1	1	1	1	0	0
** Subtotal **			0	7	8	10	7	0	0	7	7	7	13	6	1	0	0
** MPS **																	
EA-01	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
EA-01	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
EA-01	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
EA-02	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
EA-02	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
EA-02	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
FS-01	BI	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
JU-01	BI	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
LA-01	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
LA-01	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
LA-01	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
LA-01	BI	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
NB-03	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
NB-03	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
NB-03	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
NB-03	BI	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
SU-03	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
SU-03	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
SU-03	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
SU-12	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	12
SU-12	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	12

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
SU-12	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	12
SU-12	BI	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	8
TW-05A	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
TW-05A	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
TW-05A	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
TW-05A	BI	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
TW-06B	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
TW-06B	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
TW-06B	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
TW-06B	BI	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
** Subtotal **			0	0	0	0	0	0	0	0	0	0	0	0	0	0	86
** S00 **																	
FS-01	CMD	118A36	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	118C24	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	130J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
FS-01	CMD	146E12	0	0	0	0	0	0	0	0	0	1	1	0	0	0	0
FS-01	CMD	153E16	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
FS-01	CMD	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	1HML27	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
FS-01	CMD	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
FS-01	CMD	1V2236	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
FS-01	CMD	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	218A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	246E36	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	253E16	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
FS-01	CMD	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
FS-01	CMD	2V2224	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
FS-01	CMD	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	318A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
FS-01	CMD	318C24	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
FS-01	CMD	346E24	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
FS-01	CMD	353E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	3HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
FS-01	CMD	3V2212	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	3V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	446E24	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
FS-01	CMD	453E16	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
FS-01	CMD	4HML27	0	0	0	0	0	0	0	1	0	1	0	0	0	0	0
FS-01	CMD	553E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	553EXX	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	5HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
FS-01	CMD	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
FS-01	CMD	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
FS-01	CMD	F15316	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
FS-01	CMD	F18A36	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	F18C24	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	F18R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	F1E605	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	F1H127	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
FS-01	CMD	F1V224	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
FS-01	CMD	F25316	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
FS-01	CMD	F28A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	F28R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	F2E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	F2H127	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
FS-01	CMD	F2V224	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
FS-01	CMD	F30J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
FS-01	CMD	F34624	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
FS-01	CMD	F35316	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
FS-01	CMD	F38A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
FS-01	CMD	F38C24	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
FS-01	CMD	F3E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	F3H127	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
FS-01	CMD	F3V224	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	F44624	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
FS-01	CMD	F45316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	F46FSP	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
FS-01	CMD	F4H127	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
FS-01	CMD	F54636	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	F55316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
FS-01	CMD	F5H127	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
JU-01	SO	118A36	4	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	118C24	4	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	130J12	2	0	0	2	0	0	0	0	0	2	0	0	0	0	0
JU-01	SO	146E12	0	0	0	0	0	0	0	0	0	2	2	0	0	0	0
JU-01	SO	153E16	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
JU-01	SO	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
JU-01	SO	1HML27	0	0	0	0	0	4	0	4	0	0	0	0	0	0	0
JU-01	SO	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	4	0	0
JU-01	SO	1V2236	0	0	0	0	0	4	4	0	0	0	0	0	0	0	0
JU-01	SO	1V8R14	0	2	2	2	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	218A36	0	4	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	246E36	0	0	0	0	4	0	0	0	0	0	0	0	0	0	0
JU-01	SO	253E16	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
JU-01	SO	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	2HML27	0	0	0	0	0	0	0	0	0	4	0	0	0	0	0
JU-01	SO	2V2224	0	0	0	0	0	0	4	0	0	0	0	0	0	0	0
JU-01	SO	2V8R14	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	318A36	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
JU-01	SO	318C24	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
JU-01	SO	346E24	0	0	0	0	0	0	0	0	0	4	0	0	0	0	0
JU-01	SO	353E16	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
JU-01	SO	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	3HML27	0	0	0	0	0	0	0	0	0	4	0	0	0	0	0
JU-01	SO	3V2212	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
JU-01	SO	3V8R14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	446E24	0	0	0	0	0	0	0	0	0	4	0	0	0	0	0
JU-01	SO	453E16	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
JU-01	SO	4HML27	0	0	0	0	0	0	0	4	0	4	0	0	0	0	0
JU-01	SO	553E16	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
JU-01	SO	553EXX	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
JU-01	SO	5HML27	0	0	0	0	0	0	0	0	0	4	0	0	0	0	0
JU-01	SO	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
JU-01	SO	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
JU-01	SO	F15316	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
JU-01	SO	F18A36	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	F18C24	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	F18R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	F1E605	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	F1H127	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
JU-01	SO	F1V224	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
JU-01	SO	F25316	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
JU-01	SO	F28A36	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	F28R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	F2E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	F2H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
JU-01	SO	F2V224	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
JU-01	SO	F30J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
JU-01	SO	F34624	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
JU-01	SO	F35316	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
JU-01	SO	F38A36	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
JU-01	SO	F38C24	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
JU-01	SO	F3E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
JU-01	SO	F3H127	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
JU-01	SO	F3V224	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
JU-01	SO	F44624	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
JU-01	SO	F45316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
JU-01	SO	F46FSP	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
JU-01	SO	F4H127	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
JU-01	SO	F54636	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
JU-01	SO	F55316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
JU-01	SO	F5H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-01	RMD	118C24	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	130J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SU-01	RMD	146E12	0	0	0	0	0	0	0	0	0	1	1	0	0	0	0
SU-01	RMD	153E16	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
SU-01	RMD	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	1HML27	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-01	RMD	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
SU-01	RMD	1V2236	0	0	0	0	0	3	3	0	0	0	0	0	0	0	0
SU-01	RMD	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	218A36	0	3	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	246E36	0	0	0	0	3	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	253E16	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
SU-01	RMD	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	2HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-01	RMD	2V2224	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
SU-01	RMD	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	318A36	0	0	0	0	0	0	0	0	3	0	0	0	0	0	0
SU-01	RMD	318C24	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-01	RMD	346E24	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-01	RMD	353E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	3HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-01	RMD	3V2212	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	3V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	446E24	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
SU-01	RMD	453E16	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-01	RMD	4HML27	0	0	0	0	0	0	0	2	0	2	0	0	0	0	0
SU-01	RMD	553E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	553EXX	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	5HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-01	RMD	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-01	RMD	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-01	RMD	F15316	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
SU-01	RMD	F18A36	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	F18C24	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	F18R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	F1E605	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	F1H127	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-01	RMD	F1V224	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
SU-01	RMD	F25316	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
SU-01	RMD	F28A36	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	F28R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	F2E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	F2H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-01	RMD	F2V224	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
SU-01	RMD	F30J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SU-01	RMD	F34624	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-01	RMD	F35316	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-01	RMD	F38A36	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-01	RMD	F38C24	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-01	RMD	F3E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	F3H127	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-01	RMD	F3V224	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	F44624	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-01	RMD	F45316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	F46FSP	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
SU-01	RMD	F4H127	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
SU-01	RMD	F54636	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	F55316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-01	RMD	F5H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-01	CMD	118A36	3	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	118A36	3	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	118C24	3	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	130J12	2	0	0	2	0	0	0	0	0	2	0	0	0	0	0
SU-02	CMD	146E12	0	0	0	0	0	0	0	0	0	2	2	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
SU-02	CMD	153E16	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-02	CMD	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	1HML27	0	0	0	0	0	3	0	3	0	0	0	0	0	0	0
SU-02	CMD	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	3	0	0
SU-02	CMD	1V2236	0	0	0	0	0	3	3	0	0	0	0	0	0	0	0
SU-02	CMD	1V8R14	0	2	2	2	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	218A36	0	3	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	246E36	0	0	0	0	3	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	253E16	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
SU-02	CMD	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	2HML27	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
SU-02	CMD	2V2224	0	0	0	0	0	0	3	0	0	0	0	0	0	0	0
SU-02	CMD	2V8R14	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	318A36	0	0	0	0	0	0	0	0	3	0	0	0	0	0	0
SU-02	CMD	318C24	0	0	0	0	0	0	0	0	3	0	0	0	0	0	0
SU-02	CMD	346E24	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
SU-02	CMD	353E16	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	3HML27	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
SU-02	CMD	3V2212	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	3V8R14	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	446E24	0	0	0	0	0	0	0	0	0	3	0	0	0	0	0
SU-02	CMD	453E16	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-02	CMD	4HML27	0	0	0	0	0	0	0	3	0	3	0	0	0	0	0
SU-02	CMD	553E16	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	553EXX	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	5HML27	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0
SU-02	CMD	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-02	CMD	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-02	CMD	F18A36	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	F18C24	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	F18R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	F1E605	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	F1H127	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-02	CMD	F1V224	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
SU-02	CMD	F28A36	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	F28R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	F2E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	F2H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-02	CMD	F2V224	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
SU-02	CMD	F30J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SU-02	CMD	F34624	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-02	CMD	F35316	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-02	CMD	F38A36	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-02	CMD	F38C24	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-02	CMD	F3E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	F3H127	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-02	CMD	F3V224	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	F44624	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-02	CMD	F45316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	F46FSP	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
SU-02	CMD	F4H127	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
SU-02	CMD	F54636	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	F55316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-02	CMD	F5H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-03	CMD	130J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SU-03	CMD	146E12	0	0	0	0	0	0	0	0	0	1	1	0	0	0	0
SU-03	CMD	153E16	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
SU-03	CMD	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-03	CMD	253E16	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
SU-03	CMD	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-03	CMD	353E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-03	CMD	3V2212	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-03	CMD	3V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-03	CMD	453E16	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-03	CMD	553E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-03	CMD	553EXX	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-04	SRD	1HML27	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-05	SRD	118A36	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	SRD	118C24	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	SRD	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
SU-05	SRD	1V2236	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
SU-05	SRD	218A36	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	SRD	246E36	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-05	SRD	2HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-05	SRD	2V2224	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
SU-05	SRD	318A36	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-05	SRD	318C24	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-05	SRD	346E24	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-05	SRD	3HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
SU-05	SRD	446E24	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-05	SRD	4HML27	0	0	0	0	0	0	0	2	0	2	0	0	0	0	0
SU-05	SRD	5HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-05	SAD	118A36	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	SAD	118C24	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	SAD	1HML27	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
SU-05	SAD	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
SU-05	SAD	1V2236	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
SU-05	SAD	218A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	SAD	246E36	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-05	SAD	2HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
SU-05	SAD	2V2224	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
SU-05	SAD	318A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-05	SAD	318C24	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-05	SAD	346E24	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
SU-05	SAD	3HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
SU-05	SAD	446E24	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-05	SAD	4HML27	0	0	0	0	0	0	0	1	0	1	0	0	0	0	0
SU-05	SAD	5HML27	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
SU-05	RMD	118A36	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	RMD	1V2236	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
SU-05	RMD	218A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	RMD	246E36	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-05	RMD	318A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-05	CMD	118A36	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	CMD	1V2236	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
SU-05	CMD	218A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-05	CMD	246E36	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-05	CMD	318A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-12	RMD	118A36	4	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	118C24	4	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	130J12	2	0	0	2	0	0	0	0	0	2	0	0	0	0	0
SU-12	RMD	146E12	0	0	0	0	0	0	0	0	0	2	2	0	0	0	0
SU-12	RMD	153E16	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-12	RMD	1E6B05	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	1HML27	0	0	0	0	0	4	0	4	0	0	0	0	0	0	0
SU-12	RMD	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	4	0	0
SU-12	RMD	1V2236	0	0	0	0	0	4	4	0	0	0	0	0	0	0	0
SU-12	RMD	1V8R14	0	2	2	2	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	218A36	0	4	0	0	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
SU-12	RMD	246E36	0	0	0	0	4	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	253E16	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
SU-12	RMD	2E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	2HML27	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
SU-12	RMD	2V2224	0	0	0	0	0	0	4	0	0	0	0	0	0	0	0
SU-12	RMD	2V8R14	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	318A36	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
SU-12	RMD	318C24	0	0	0	0	0	0	0	0	4	0	0	0	0	0	0
SU-12	RMD	346E24	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
SU-12	RMD	353E16	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	3E6B05	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	3HML27	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
SU-12	RMD	3V2212	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	3V8R14	0	0	2	2	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	446E24	0	0	0	0	0	0	0	0	0	4	0	0	0	0	0
SU-12	RMD	453E16	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-12	RMD	4HML27	0	0	0	0	0	0	0	4	0	4	0	0	0	0	0
SU-12	RMD	553E16	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	553EXX	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	5HML27	0	0	0	0	0	0	0	0	0	0	4	0	0	0	0
SU-12	RMD	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
SU-12	RMD	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-12	RMD	F15316	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
SU-12	RMD	F18A36	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	F18C24	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	F18R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	F1E605	0	1	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	F1H127	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-12	RMD	F1V224	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
SU-12	RMD	F25316	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
SU-12	RMD	F28A36	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	F28R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	F2E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	F2H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	RMD	F2V224	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
SU-12	RMD	F30J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SU-12	RMD	F34624	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	RMD	F35316	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-12	RMD	F38A36	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-12	RMD	F38C24	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
SU-12	RMD	F3E605	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	F3H127	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-12	RMD	F3V224	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	F44624	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-12	RMD	F45316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	F46FSP	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
SU-12	RMD	F4H127	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
SU-12	RMD	F54636	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	F55316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	RMD	F5H127	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	CMD	118A36	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	118C24	2	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	130J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SU-12	CMD	146E12	0	0	0	0	0	0	0	0	0	1	1	0	0	0	0
SU-12	CMD	153E16	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
SU-12	CMD	1E6B05	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	1HML27	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-12	CMD	1RS46E	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0
SU-12	CMD	1V2236	0	0	0	0	0	2	2	0	0	0	0	0	0	0	0
SU-12	CMD	1V8R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	218A36	0	2	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	246E36	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	253E16	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
SU-12	CMD	2HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	CMD	2V2224	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0
SU-12	CMD	2V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	318A36	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-12	CMD	318C24	0	0	0	0	0	0	0	0	2	0	0	0	0	0	0
SU-12	CMD	346E24	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	CMD	353E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	3HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	CMD	3V2212	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	3V8R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	446E24	0	0	0	0	0	0	0	0	0	2	0	0	0	0	0
SU-12	CMD	453E16	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-12	CMD	4HML27	0	0	0	0	0	0	0	2	0	2	0	0	0	0	0
SU-12	CMD	553E16	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	553EXX	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	5HML27	0	0	0	0	0	0	0	0	0	0	2	0	0	0	0
SU-12	CMD	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
SU-12	CMD	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
SU-12	CMD	F15316	0	0	0	0	0	2	0	2	0	0	0	0	0	0	0
SU-12	CMD	F18A36	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	F18C24	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	F18R14	0	1	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	F1H127	0	0	0	0	0	1	0	1	0	0	0	0	0	0	0
SU-12	CMD	F1V224	0	0	0	0	0	1	1	0	0	0	0	0	0	0	0
SU-12	CMD	F25316	0	0	0	0	0	0	0	2	0	0	0	0	0	0	0
SU-12	CMD	F28A36	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	F28R14	0	0	1	1	0	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	F2H127	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-12	CMD	F2V224	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
SU-12	CMD	F30J12	1	0	0	1	0	0	0	0	0	1	0	0	0	0	0
SU-12	CMD	F34624	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-12	CMD	F35316	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-12	CMD	F38A36	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-12	CMD	F38C24	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
SU-12	CMD	F3H127	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-12	CMD	F3V224	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	F44624	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
SU-12	CMD	F45316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	F46FSP	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
SU-12	CMD	F4H127	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0
SU-12	CMD	F54636	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	F55316	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
SU-12	CMD	F5H127	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
** Subtotal **			83	65	46	94	96	83	67	96	67	106	122	6	35	0	0
** <u>ZZC</u> **																	
EA-01	EAF	BEAFFW	1	1	1	2	0	0	0	0	1	0	0	0	0	0	0
EA-01	EAF	BEAFRW	0	0	0	0	1	0	1	0	0	1	1	0	0	0	0
EA-01	EAF	PALMXX	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
EA-01	EAF	T30F14	0	0	0	0	0	0	0	0	0	0	0	1	1	0	0
EA-01	EAF	TV8B14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0
EA-01	EAF	WGISSX	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
EA-02	EAF	BEAFFW	1	1	1	2	0	0	0	0	1	0	0	0	0	0	0
EA-02	EAF	BEAFRW	0	0	0	0	1	0	1	0	0	1	1	0	0	0	0
EA-02	EAF	PALMXX	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
EA-02	EAF	TFRS11	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
EA-02	EAF	TV8B14	0	0	0	2	0	0	0	0	0	0	0	0	0	0	0

USMC MF TBA by Division

CONFIG	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
SU-03	EAF	BEAFFW	1	1	1	2	0	0	0	0	1	0	0	0	0	0	0
SU-03	EAF	BEAFRW	0	0	0	0	1	0	1	0	0	1	1	0	0	0	0
** Subtotal **			6	3	3	10	4	0	3	0	3	3	3	1	1	0	0
Total			415	310	245	416	284	239	248	295	311	302	338	193	221	39	86

USMC MF TBA Support Equipment by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
** <u>ANCILLARY</u> **																	
900	990	CCSPFW	1	1	1	1	0	0	0	0	1	0	0	1	0	0	0
900	990	CCSPRW	0	0	0	0	1	1	1	1	0	1	1	0	1	0	0
** Subtotal **			1	1	1	1	1	1	1	1	1	1	1	1	1	0	0
** <u>CDT</u> **																	
900	990	CCSPFW	2	2	2	2	0	0	0	0	2	0	0	2	0	0	0
900	990	CCSPRW	0	0	0	0	2	2	2	2	0	2	2	0	2	0	0
900	990	HMXXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	2	0
** Subtotal **			2	2	2	2	2	2	2	2	2	2	2	2	2	2	0
** <u>E-TOOL</u> **																	
900	990	CCSPFW	3	3	3	3	0	0	0	0	3	0	0	3	0	0	0
900	990	CCSPRW	0	0	0	0	3	2	3	3	0	3	3	0	3	0	0
900	990	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
** Subtotal **			3	3	3	3	3	2	3	0	2						
** <u>LOAD BANK</u> **																	
900	990	CCSPFW	6	6	6	6	0	0	0	0	6	0	0	5	0	0	0
900	990	CCSPRW	0	0	0	0	4	2	4	4	0	4	4	0	4	0	0
MPS	MPS	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2
** Subtotal **			6	6	6	6	4	2	4	4	6	4	4	5	4	0	2
** <u>MEP-807A</u> **																	
900	990	CCSPFW	12	12	12	12	0	0	0	0	12	0	0	12	0	0	0
900	990	CCSPRW	0	0	0	0	5	5	5	5	0	5	5	0	5	0	0
900	990	PALMXX	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
MPS	MP1	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	13
MPS	MP2	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	13
MPS	MP3	MPSXXX	0	0	0	0	0	0	0	0	0	0	0	0	0	0	13
ZZB	WX	MACSXX	4	2	2	4	2	0	2	0	2	2	2	0	0	0	0
** Subtotal **			17	14	14	16	7	5	7	5	14	7	7	12	5	0	39
** <u>MEP-809A</u> **																	
900	990	CCSPFW	18	18	18	18	0	0	0	0	18	0	0	18	0	0	0
900	990	CCSPRW	0	0	0	0	14	7	14	14	0	14	14	0	14	0	0
** Subtotal **			18	18	18	18	14	7	14	14	18	14	14	18	14	0	0
** <u>MMG-1A</u> **																	
900	990	CCSPFW	10	10	10	10	0	0	0	0	10	0	0	10	0	0	0
900	990	CCSPRW	0	0	0	0	8	8	8	8	0	8	8	0	8	0	0
** Subtotal **			10	10	10	10	8	8	8	8	10	8	8	10	8	0	0

USMC MF TBA Support Equipment by Configuration Code

DIV	BR	CSP	M11	M12	M13	M14	M16	M24	M26	M29	M31	M36	M39	M41	M49	HMX	MPS
**	<u>PW-BX</u>	**															
900	990	CCSPFW	5	5	5	5	0	0	0	0	5	0	0	5	0	0	0
900	990	CCSPRW	0	0	0	0	4	4	4	4	0	4	4	0	4	0	0
** Subtotal **			5	5	5	5	4	4	4	4	5	4	4	5	4	0	0
** <u>RECLAMATOR</u> **																	
900	990	CCSPFW	3	3	6	3	0	0	0	0	3	0	0	3	0	0	0
900	990	CCSPRW	0	0	0	0	3	3	3	3	0	3	3	0	3	0	0
** Subtotal **			3	3	6	3	3	3	3	3	3	3	3	3	3	0	0
** <u>SCAFFOLD</u> **																	
900	990	CCSPFW	4	4	4	4	0	0	0	0	4	0	0	4	0	0	0
900	990	CCSPRW	0	0	0	0	4	4	4	4	0	4	4	0	4	0	0
** Subtotal **			4	4	4	4	4	4	4	4	4	4	4	4	4	0	0
Total			69	66	69	68	50	38	50	48	66	50	50	63	48	2	43

Mobile Facility/Ancillary Equipment/Administrative Note Cross
Reference

CODE	CONFIGURATION
AB-02	AIRCREW BRIEF/DEBRIEF MF #1
AB-03	AIRCREW BRIEF/DEBRIEF MF #2
AM-01	IMRL MANAGEMENT
AT-08	SQUADRON GROUND SYSTEM
AT-09BM	ATARS POD MAINTENANCE
AT-10A	ATARS PALLET MAINTENANCE
AT-11	EQUIPMENT MAINTENANCE/ATC
AT-12	ADMINISTRATIVE SUPPORT/ATC
BR-01	BRU-33A MAINTENANCE
BR-04A	BRU-33 MF A MAINTENANCE
BR-05B	BRU-33 MF B MAINTENANCE
CA-01	ELECTRO-MECHANICAL
CA-04	PHYSICAL MECHANICAL CALIBRATION
CA-07A	OPTICAL/DIMENSIONAL CALIBRATION MF A
CA-08B	OPTICAL/DIMENSIONAL CALIBRATION MF B
CA-09	PHYSICAL DIMENSIONAL CALIBRATION
CL-01	"I" LEVEL CAL PHASES A, B, C, D
CL-02	"I" LEVEL CAL PHASES E, F
CL-04	TEST EQUIPMENT REPAIR
CL-06	CALIBRATION MANAGEMENT
CL-07	TEST EQUIPMENT STAGING
CL-09	AIMS/TACAN CALIBRATION
CL-10	PHYSICAL DIMENSIONAL CALIB
CR-03	MICRO MINIATURE REPAIR/ATC
CR-04	MICRO MINIATURE REPAIR
CS-02A	COMPOSITE REPAIR/METAL SHOP MF A
CS-03BM	COMPOSITE REPAIR/METAL SHOP MF B MODIFIED
CU-01	MANAGEMENT CONTROL
CY-01	COMMUNICATION SECURITY MAINTENANCE
DP-03	SUPPLY ADP MGMT CENTER
DP-04	SUPPLY ADP TAPE LIBRARY
DP-18A	NTCSS
EA-01	EAF MECHANICAL
EA-02	EAF ELECTRICAL
EB-06	EA6B RFI POOL

Mobile Facility/Ancillary Equipment/Administrative Note Cross
Reference

CODE	CONFIGURATION
EB-07	EA6B ANTENNA, RF HEAD POOL
EB-08	EA6B RECEIVER, AWP/AWM
EB-09	EA6B TRANSMITTER, AWP/AWM
EB-14A	EA6B ALM-249/250/251 MF A
EB-15B	EA6B ALM-249/250/251 MF B
FA-02A	SERVO CYLINDER T/S MF A
FA-03B	SERVO CYLINDER T/S MF B
FC-05	FOSAMS
FS-01	FLAMMABLE STORAGE
GC-01	GENERATOR CONTROL UNIT T/S
GM-02A	ORD REPAIR MF A
GM-03B	ORD REPAIR MF B
HC-01	HYDRAULIC COMPONENT ASSEMBLY
HC-02	HYDRAULIC COMPONENT DISASSEMBLY
HT-01B	HYBRID TEST SYSTEM AN/USM-484 MF B
HT-02A	HYBRID TEST SYSTEM AN/USM-484 MF A
HT-03	HYBRID TEST SYSTEM TPS STORAGE
HY-04A	HYDRAULIC TEST SET A/F27T-10 MF A
HY-05B	HYDRAULIC TEST SET A/F27T-10 MF B
HY-06C	MV-22 LANDING GEAR TEST FIXTURE
JU-01	INTEGRATION UNIT, STANDARD
JU-09	INTEGRATION UNIT, EA6B #1
JU-10	INTEGRATION UNIT, EA6B #2
JU-31	INU, F-18 BRIEF/DEBRIEF
JU-32	INU, F-18 TRAINING UNIT # 1
KA-01A	CASS HYBRID TEST STATION MF A
KA-02B	CASS HYBRID TEST STATION MF B
KA-03A	CASS CNI TEST STATION MF A
KA-04B	CASS CNI TEST STATION MF B
KA-05A	CASS RF TEST STATION MF A
KA-06B	CASS RF TEST STATION MF B
KA-07A	CASS ELECTRO-OPTICAL TEST STATION MF A
KA-08B	CASS ELECTRO-OPTICAL TEST STATION MF B
KA-18A	CASS RT TEST STATION (USMC)
KA-19A	CASS HI POWER SOMF A
KA-20B	CASS HI POWER SOMF B

Mobile Facility/Ancillary Equipment/Administrative Note Cross
Reference

CODE	CONFIGURATION
KA-31	OTPS STORAGE
LA-01	LEAD ACID BATTERY
MC-01	MAINT/PRODUCTION CONTROL
MM-01	MACHINE SHOP , GRINDER
MM-02	MACHINE SHOP, MILLING MACHINE
MM-03	MACHINE SHOP, LATHE
MM-04	MACHINE SHOP, DRILLING
NB-03	NICAD BATTERY CHARGE
NT-06	NON-DESTRUCT TEST
NT-07	XRAY PROCESSOR
NT-08	MAGNETIC PARTICLE MF
NV-01	NIGHT VISION SUPPORT
PM-01	COUNTERMEASURES CHAFF DISPENSER POD MAINT
PM-02	UNIVERSAL POD MAINTENANCE
PP-01	POWER PLANTS
PP-03A	POWER PLANTS MF A
PP-04BM	POWER PLANTS MF B MODIFIED
RR-02	OXYGEN REPAIR
RR-03	ABO ANNALYZER
RR-04A	OXYGEN TEST/REPAIR (RW) MFA
RR-05B	OXYGEN TEST/REPAIR (RW) MFB
RT-10	RADCOM TPS STORAGE
RT-11A	RADCOM/APS 124 OTSP MF A
RT-12B	RADCOM USM-467/RIU MF B
SE-01	SURVIVAL EQUIPMENT #1
SE-02B	SURVIVAL EQUIPMENT #2
SE-03C	SURVIVAL EQUIPMENT #3
SE-04B	SURVIVAL EQUIPMENT #4
SE-05	SURVIVAL EQUIP, MERWS
SE-06C	SURVIVAL EQUIP MERWS STORAGE MF C
SH-03	NEWTS AN/USM-458
SH-04	NEWTS AN/USM-458 SUPPORT
SH-06	A/C SURVIVABILITY EQUIPMENT
SM-04B	SHEET METAL SHOP 1 MF B
SM-05A	SHEET METAL SHOP 1 MF A
SM-06B	SHEET METAL SHOP 2 MF B

Mobile Facility/Ancillary Equipment/Administrative Note Cross
Reference

CODE	CONFIGURATION
SM-07A	SHEET METAL SHOP 2 MF A
SP-04	NOAP (NAVAL OIL ANALYSIS PROGRAM) MF
ST-01	STANDARD MF
SU-01	AVIATION SUPPLY, SHELVES
SU-02	AVIATION SUPPLY, CABINETS
SU-03	AVIATION SUPPLY
SU-05	SUPPLY SUPPORT CENTER
SU-08	SHIPPING/RECEIVING
SU-12	SUPPLY, BULK STORAGE
SW-02	NITROGEN RECEIVER FILL/REPAIR
TB-01	TUBE BENDER MF
TB-02	MV-22 TUBE BENDER MF
TL-01	TECH LIBRARY
TR-01	TOOL ROOM
TT-02	TURRET TEST SUPPORT
TT-03A	TURRET TEST MF A
TT-04B	TURRET TEST MF B
TW-05A	ACFT TIRE/WHEEL BUILD-UP MF A
TW-06B	ACFT TIRE/WHEEL BUILD-UP MF B
VD-05A	ACFT ENGINE COMPNENT TEST STAND (RW)
VD-06B	ACFT ENGINE COMPNENT TEST STAND (RW)
VD-07A	ACFT ENGINE COMPNENT TEST STAND (FW)
VD-08B	ACFT ENGINE COMPNENT TEST STAND (FW)
WC-02	QUALITY ASSURANCE
WC-08	SUPPORT EQUIPMENT MAINT
WC-12A	WORK CENTER 990 MF A
WC-13BM	WORK CENTER 990 MF B-MOD
WJ-06	METROLOGY MF
WL-04A	WELDING SHOP MF A
WL-05A	WELDING SHOP MF B
WR-01	WIRE REPAIR
ANCILLARY	ANCILLARY MF
CDT	COMPLEXING/DECOMPLEXING TOOL
E-TOOL	TACTICAL QUIET GENERATOR TROUBLESHOOTING COMPUTER
LOAD BANK	RESISTIVE LOAD BANK, LPH200
MEP-807A	GENERATOR, TACTICAL QUIET 100KW

**Mobile Facility/Ancillary Equipment/Administrative Note Cross
Reference**

CODE	CONFIGURATION
MEP-809A	GENERATOR, TACTICAL QUIET 200KW
MMG-1A	MOTOR GENERATOR FREQUENCY CONVERTER
PDB	POWER DISTRIBUTION BOX
PW-BX	ANCILLARY MF, POWER DISTRIBUTION BOX
SCAFFOLD	CATWALK AND STAIRS
RECLAMATOR	REFRIGERANT RECOVERY/RECYCLING UNIT

NAMING CONVENTION TO DESCRIPTION CROSS REFERENCE

NAME	DESCRIPTION
118A12	12 A/C F/A-18A PCSP
118A36	36 A/C F/A-18A PCSP
118C24	24 A/C F/A-18C PCSP
130J12	12 A/C KC-130J PCSP
130T12	12 A/C KC-130T PCSP
130OEF	12 A/C KC-130J PCSP
146E12	12 A/C CH-46E PCSP
146E36	36 A/C CH-46E PCSP
153D10	10 A/C CH-53D PCSP
153DRW	10 A/C CH-53D FOSP
153E16	16 A/C CH-53E PCSP
1E6B05	5 A/C EA-6B PCSP
1H1BW7	7 A/C H-1 MEU RESP
1H1Y09	9 A/C UH-1Y PCSP
1HML09	9 A/C H-1 PCSP 4 TH MAW
1HML27	27 A/C 9 UH-1N/18 AH-1W PCSP
1RS46E	X A/C CH-46E PCSP 4 TH MAW
1RS53E	X A/C CH-53E PCSP 4 TH MAW
1RSAH1	X A/C AH-1W PCSP 4 TH MAW
1RSUH1	X A/C UH-1N PCSP 4 TH MAW
1V2236	36 A/C V-22 PCSP
1V8R14	14 A/C AV-8B PCSP
2130J2	XX A/C KC-130J PCSP
218A36	36 A/C F/A-18A PCSP (2ND PKG ON SITE)
246E36	36 A/C CH-46E PCSP (2ND PKG ON SITE)

Mobile Facility/Ancillary Equipment/Administrative Note Cross
Reference

NAME	DESCRIPTION
253D10	10 A/C CH-53D PCSP (2ND PKG ON SITE)
253E16	16 A/C CH-53E PCSP (2ND PKG ON SITE)
2E6B05	5 A/C EA-6B PCSP (2ND PKG ON SITE)
2H1Y09	9 A/C UH-1Y PCSP (2ND PKG ON SITE)
2HML09	9 A/C H-1 PCSP 4 TH MAW (2ND PKG ON SITE)
2HML27	27 A/C 9 UH-1N/18 AH-1W PCSP (2ND PKG ON SITE)
2RS46E	X A/C CH-46E PCSP 4 TH MAW (2ND PKG ON SITE)
2V2224	24 A/C V-22 PCSP (2ND PKG ON SITE)
2V8R14	14 A/C AV-8B PCSP (2ND PKG ON SITE)
318A36	36 A/C F/A-18A PCSP (3RD PKG ON SITE)
318C24	24 A/C F/A-18C PCSP (3RD PKG ON SITE)
346E24	24 A/C CH-46E PCSP (3RD PKG ON SITE)
353D10	10 A/C CH-53D PCSP (3RD PKG ON SITE)
353E16	16 A/C CH-53E PCSP (3RD PKG ON SITE)
3E6B05	5 A/C EA-6B PCSP (3RD PKG ON SITE)
3HML09	9 A/C H-1 PCSP 4 TH MAW (3RD PKG ON SITE)
3HML27	27 A/C 9 UH-1N/18 AH-1W PCSP (3RD PKG ON SITE)
3M14RP	XX A/C KC-130J PCSP
3V2212	12 A/C V-22 PCSP (3RD PKG ON SITE)
3V8R14	14 A/C AV-8B PCSP (3RD PKG ON SITE)
446E24	24 A/C CH-46E PCSP (4TH PKG ON SITE)
453E16	16 A/C CH-53D PCSP (4TH PKG ON SITE)
4HML09	9 A/C H-1 PCSP 4 TH MAW (4TH PKG ON SITE)
4HML27	27 A/C H-1 PCSP 4 TH MAW (4TH PKG ON SITE)
518N36	36 A/C F/A-18A PCSP (5TH PKG ON SITE)
553E04	04 A/C CH-53E PCSP (5TH PKG ON SITE)
553E16	16 A/C CH-53E PCSP (5TH PKG ON SITE)
553EXX	XX A/C CH-53E PCSP (5TH PKG ON SITE)
5HML27	27 A/C H-1 PCSP (5TH PKG ON SITE)
BEAFFW	EAF F/W PCSP
BEAFRW	EAF R/W PCSP
CCSP13	MALS-13 CCSP (OEF)
CCSP14	MALS-14 CCSP (OEF)
CCSPFW	COMMON CSP FOR A FIXED WING MALS
CCSPRW	COMMON CSP FOR A ROTARY WING MALS
F1130T	FISP, 12 A/C KC-130T

Mobile Facility/Ancillary Equipment/Administrative Note Cross
Reference

NAME	DESCRIPTION
F15310	FISP, 10 A/C CH-53E
F15316	FISP, 16 A/C CH-53E
F18A36	FISP, 36 A/C F/A-18A
F18C24	FISP, 24 A/C F/A-18C
F18R14	FISP, 14 A/C AV-8B
F1E605	FISP, 5 A/C EA-6B
F1H127	FISP, 27 A/C 9 UH-1N/18 AH-1W
F1HY09	FISP, H-1
F1MEU1	MESP, MV-22
F1V224	FISP, 24 A/C MV-22
F25310	FISP, 10 A/C CH-53E (2ND PKG ON SITE)
F25316	FISP, 16 A/C CH-53E (2ND PKG ON SITE)
F28A36	FISP, 36 A/C F/A-18A (2ND PKG ON SITE)
F28R14	FISP, 14 A/C AV-8B (2ND PKG ON SITE)
F2E605	FISP, 5 A/C EA-6B (2ND PKG ON SITE)
F2H127	FISP, 27 A/C 9 UH-1N/18 AH-1W (2ND PKG ON SITE)
F2V224	FISP, 24 A/C MV-22 (2ND PKG ON SITE)
F30J12	FISP, 12 A/C KC-130J (3RD PKG ON SITE)
F34624	FISP, 24 A/C CH-46E (3RD PKG ON SITE)
F35310	FISP, 10 A/C CH-53D (3RD PKG ON SITE)
F35316	FISP, 16 A/C CH-53E (3RD PKG ON SITE)
F38A36	FISP, 36 A/C F/A-18A (3RD PKG ON SITE)
F38C24	FISP, 24 A/C F/A-18C (3RD PKG ON SITE)
F3E605	FISP, 5 A/C EA-6B (3RD PKG ON SITE)
F3H127	FISP, 27 A/C 9 UH-1N/18 AH-1W (3RD PKG ON SITE)
F3V224	FISP, 24 A/C MV-22 (3RD PKG ON SITE)
F44624	FISP, 24 A/C CH-46E (3RD PKG ON SITE)
F45316	FISP, 16 A/C CH-53E (3RD PKG ON SITE)
F46FSP	FISP, XX A/C CH-46E (4TH PKG ON SITE)
F4H127	FISP, 27 A/C 9 UH-1N/18 AH-1W (4TH PKG ON SITE)
F53MEU	FISP, XX A/C CH-53E (MEU)
F54636	FISP, 36 A/C CH-46E (5TH PKG ON SITE)
F55316	FISP, 16 A/C CH-53E (5TH PKG ON SITE)
F5H127	FISP, 27 A/C 9 UH-1N/18 AH-1W (5TH PKG ON SITE)
FBWXIF	RESP, MALS-13 (MEU)
FBWXIR	RESP, MALS-13 (MEU)

Mobile Facility/Ancillary Equipment/Administrative Note Cross
Reference

NAME	DESCRIPTION
FBWXOF	RESP, MALS-13 (MEU)
FBWXOR	RESP, MALS-13 (MEU)
IOSPXX	FOLLOW-ON SUPPORT IDENTIFIED BY ACTIVITY I.E. FOSP11, FOSP12, FOSP13, ETC.
HMXXXX	MARINE HELICOPTER SQUADRON 1
I18A11	FOLLOW-ON SUPPORT IDENTIFIED BY T/M/S & ACTIVITY I.E. I18A11, I18A31, I53E36, IV8R12, LH46RS, ETC.
MACSXX	MARINE AIR CONTROL SQUADRON
MPSXXX	EQUIPMENT CONTROLLED BY BLOUNT ISLAND COMMAND
PALMXX	EAF, AGSE 29 PALM
SCIFXX	IDENTIFIES EQUIPMENT ADMINISTRATIVELY CONTROLLED BY THE INDICATED ACTIVITY BUT OPERATIONALLY CONTROLLED BY CMC
TXXXXX	TRAINING SUPPORT ACTIVITY CSP IDENTIFIED BY ACTIVITY I.E. TFRS11, T30F14, T53E29, ETC
WAISSX	INTERIM SUPPORT ALLOWANCE (ISAL)
WEATHF	WEATHER SUPPORT F/W CSP
WEATHR	WEATHER SUPPORT R/W CSP
WGISSX	INTERIM SUPPORT ALLOWANCE (ISAL)
WSTOCK	INTERIM SUPPORT ALLOWANCE (ISAL)

ADMINISTRATIVE NOTES

(A) Whenever the integration units are calculated within a package, the allowance is 1 JU-01 per 6 MF's rated. If there are any additional MF's after the quantity is determined, an additional asset will be authorized when 4 units are rated. Example: If you have 10 MF's authorized you will be authorized 2 JU-01's or equivalent.

Sample MF User O-Level Maintenance Syllabus

Name _____ Rank _____ W/C / MOS _____

The following training is required for all E-7 and below assigned to MALS departments and supported units (i.e. EAF, Weather and MCAS) that have mobile facility allocations in accordance with Encl (6) of MCO 13670.1.

The Mobile Facility Coordinator (MFC) shall maintain a copy of this training track in W/C 60C for all trained personnel currently assigned to the MALS or a unit that receives MF support from the MALS (i.e., EAF, Weather, and MACS).

The W/C supervisor shall maintain a copy of this training track for all personnel assigned to the W/C.

Periodic Maintenance (PM) Training

Training will be conducted by a W/C 60C CDI on proper procedures for completion of the MF and ECU PM. During this training, the work will be conducted by the MF user with the W/C 60C CDI providing instruction. Training will be hands on training using a MF and NAVAIR-19-600-152-6-2 or NAVAIR 19-600-141-6-2 as a training aid.

91 Day MF PM	MCN _____	Date _____	CDI _____
182 Day MF PM	MCN _____	Date _____	CDI _____
364 Day MF PM	MCN _____	Date _____	CDI _____
91 Day ECU PM	MCN _____	Date _____	CDI _____
365 Day ECU PM	MCN _____	Date _____	CDI _____

Periodic Maintenance Performance

The MF user will perform the MF PM without W/C 60C instruction. The W/C 60C CDI will ensure proper performance of PM upon completion.

91 Day MF PM	MCN _____	Date _____	CDI _____
182 Day MF PM	MCN _____	Date _____	CDI _____
364 Day MF PM	MCN _____	Date _____	CDI _____
91 Day ECU PM	MCN _____	Date _____	CDI _____
365 Day ECU PM	MCN _____	Date _____	CDI _____

MF USER O-LEVEL MAINTENANCE QUALIFICATION

3 Jan 12

Name _____ Rank _____ W/C / MOS _____

Corrosion Prevention / Treatment

Corrosion prevention / treatment training will be provided to the MF user by a W/C 60C CDI. This training will stress the importance of *PROPER* corrosion prevention and treatment of the MF. Forklift pockets, rivets, emergency exit thumbscrews, and the seams between MF structural beams and MF walls will be given special attention during this training as these areas are most susceptible to a corrosive failure. Training will be hands on training using a MF as a training aid.

Date Training Provided _____

Training Provided By _____

Convention for Safe Container (CSC) Introduction

The MF user will receive an introduction to the CSC program from a certified CSC inspector. This training will familiarize the MF user with the purpose of the CSC program as well as common CSC failures that occur with MFs. The MF user should be able to identify structural issues that could result in failing the CSC inspection and identify these issues to W/C 60C. This introduction will not be a substitute for the AMMO-43 Intermodal Dry Cargo Container/CSC Re-inspection Course and will not certify the MF user as a CSC inspector. Training will be hands on training using a MF and MIL-HDBK-138B as a training aid.

Date Training Provided _____

Training Provided By _____

Mobile Facility Preparation for Shipping

To prevent damage to the MF and contents during shipment, MF users will receive training from a W/C 60C CDI on the proper way to prepare a MF for shipping. This training will be hands on training using a MF and the AG-360-IIN-000 as a training aid.

Date Training Provided _____

Training Provided By _____